SAMSUNG

Instruction Manual

DVD-SH853
DVD-SH855

DVD VIDEO RAM/RW DVD VIDEO COMPACT disc DIGITAL AUDIO

www.samsung.com

AK68-01462A-01

Downloaded From Disc-Player.com Samsung Manuals

Getting Started

Warning

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER (OR BACK).
NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.

This symbol indicates important instructions accompanying the product.

Do not install this equipment in a confined space such as a bookcase or similar unit.

WARNING : To prevent damage which may result in fire or electric shock hazard, do not expose this appliance to rain or moisture.

CAUTION : HDD & DVD Recorder USES AN INVISIBLE LASER BEAM WHICH CAN CAUSE HAZARDOUS RADIATION EXPOSURE IF DIRECTED. BE SURE TO OPERATE HDD & DVD Recorder CORRECTLY AS INSTRUCTED.

CAUTION
THIS PRODUCT UTILIZES A LASER.
USE OF CONTROLS OR ADJUSTMENTS OR PERFORMANCE OF PROCEDURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARDOUS RADIATION EXPOSURE.
DO NOT OPEN COVERS AND DO NOT REPAIR YOURSELF. REFER SERVICING TO QUALIFIED PERSONNEL.

This product satisfies CE regulations when shielded cables and connectors are used to connect the unit to other equipment. To prevent electromagnetic interference with electric appliances, such as radios and televisions, use shielded cables and connectors for connections.

IMPORTANT NOTE

The mains lead on this equipment is supplied with a moulded plug incorporating a fuse. The value of the fuse is indicated on the pin face of the plug. If it requires replacing, a fuse approved to BS1362 of the same rating must be used.

Never use the plug with the fuse cover omitted if the cover is detachable. If a replacement fuse cover is required, it must be of the same colour as the pin face of the plug. Replacement covers are available from your dealer.

If the fitted plug is not suitable for the power points in your house or the cable is not long enough to reach a power point, you should obtain a suitable safety approved extension lead or consult your dealer for assistance.

However, if there is no alternative to cutting off the plug, remove the fuse and then safely dispose of the plug. Do not connect the plug to a mains jack, as there is a risk of shock hazard from the bared flexible cord.

To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

The product unit accompanying this user manual is licenced under certain intellectual property rights of certain third parties. This licence is limited to private non-commercial use by end-user consumers for licenced contents.
No rights are granted for commercial use.
The licence does not cover any product unit other than this product unit and the licence does not extend to any unlicenced product unit or process conforming to ISO/IEC 11172-3 or ISO/IEC 13818-3 used or sold in combination with this product unit. The licence only covers the use of this product unit to encode and/or decode audio files conforming to the ISO/IEC 11172-3 or ISO/IEC 13818-3. No rights are granted under this licence for product features or functions that do not conform to the ISO/IEC 11172-3 or ISO/IEC 13818-3.

Downloaded From Disc-Player.com Samsung Manuals

Precaution

Important Safety Instructions

Read these operating instructions carefully before using the unit. Follow all the safety instructions listed below. Keep these operating instructions handy for future reference.

1) Read these instructions.
2) Keep these instructions.
3) Heed all warnings.
4) Follow all instructions.
5) Do not use this apparatus near water.
6) Clean only with dry cloth.
7) Do not block any ventilation openings, Install in accordance with the manufacturer's instructions.
8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9) Do not defeat the safety purpose of the polarized or grounding- type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, the point where they exit from the apparatus.
11) Only use attachments/accessories specified by the manufacturer.
12) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13) Unplug this apparatus during lightning storms or when unused for long periods of time.
14) Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

Handling Cautions

- Before connecting other components to this HDD & DVD Recorder, be sure to turn them all off.
- Do not move the HDD & DVD Recorder while a disc is being played, or the disc may be scratched or broken, the HDD & DVD Recorder internal parts may be damaged.
- Do not put a flower vase filled with water or any small metal objects on the HDD & DVD Recorder.
- Be careful not to put your hand into the disc tray.
- Do not place anything other than the disc in the disc tray.
- Exterior interference such as lightning and static electricity can affect normal operation of this HDD & DVD Recorder. If this occurs, turn the HDD & DVD Recorder off and on again with the **STANDBY/ON** button, or disconnect and then reconnect the AC power cord to the AC power outlet. The HDD & DVD Recorder will operate normally.
- Be sure to remove the disc and turn off the HDD & DVD Recorder after use.
- Disconnect the AC power cord from the AC outlet when you don't intend to use the HDD & DVD Recorder for long periods of time.
- Clean the disc by wiping in a straight line from the inside to the outside of the disc.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- The Mains plug is used as a disconnect device and shall stay readily operable at any time.

Maintenance of Cabinet

For safety reasons, be sure to disconnect the AC power cord from the AC outlet.

- Do not use benzene, thinner, or other solvents for cleaning.
- Wipe the cabinet with a soft cloth.

HDD (Hard Disk Drive)

The hard disk has a high storage density, which enables long recording durations and quick access to written data. However, it can easily be damaged by shock, vibration or dust and should be kept away from magnets. To avoid losing important data, observe the following precautions.

- Do not use the HDD & DVD Recorder in a place subject to extreme changes in temperature.

Downloaded From Disc-Player.com Samsung Manuals

- Do not apply a strong shock to the HDD & DVD Recorder.
- Do not place the HDD & DVD Recorder in a location subject to mechanical vibrations or in an unstable location.
- Do not place the HDD & DVD Recorder on top of a heat source.
- Do not disconnect the AC power cord while the power is on.
- Do not attempt to change the hard disk. This may result in a malfunction.

Should the hard disk be damaged, you cannot recover lost data. The hard disk is only a temporary storage space.

Disc Handling

- Use discs with regular shapes. If an irregular disc (a disc with a special shape) is used, this HDD & DVD Recorder may be damaged.



Holding discs

- Avoid touching the surface of a disc where recording is performed.

DVD-RAM, DVD±RW and DVD±R

- Clean with an optional DVD-RAM/PD disc cleaner (LF-K200DCA1 where available). Do not use cleaners or cloths for CDs to clean DVD-RAM/±RW/±R discs.

DVD-Video, Audio-CD

- Wipe off dirt or contamination on the disc with a soft cloth.

Cautions on handling discs

- Do not write on the printed side with a ball-point pen or pencil.
- Do not use record cleaning sprays or antistatic. Also, do not use volatile chemicals, such as benzene or thinner.
- Do not apply labels or stickers to discs. (Do not use discs fixed with exposed tape adhesive or leftover peeled-off stickers.)
- Do not use scratch-proof protectors or covers.
- Do not use discs printed with label printers available on the market.
- Do not load warped or cracked discs.

Disc Storage

Be careful not to harm the disc because the data on these discs is highly vulnerable to the environment.

- Do not keep under direct sunlight.
- Keep in a cool ventilated area.
- Store vertically.
- Keep in a clean protection jacket.
- If you move your HDD & DVD Recorder suddenly from a cold place to a warm place, condensation may generate on the operating parts and lens and cause abnormal disc playback. If this occurs, do not connect the plug to the power outlet and wait for two hours. Then insert the disc and try to play back again.

Disc Specifications

This unit allows you to record and playback high quality digital video on DVD-RAM/-RW/-R discs or on the HDD.
You can also edit digital images on DVD-RAM/-RW discs or HDD. (DVD+RW/+R discs can be played, but cannot be recorded.)

Disc Type

◆ DVD-Video

- A digital versatile disc (DVD) can contain up to 135-minutes of images, 8 audio languages and 32 subtitle languages. It is equipped with MPEG-2 picture compression and Dolby digital surrounding, allowing you to enjoy vivid and clear theatre quality images in the comfort of your own home.
- When switching from the first layer to the second layer of a dual-layered DVD Video disc, there may be momentary distortion in the image and sound. This is not a malfunction of the unit.
- Once a DVD-RW/-R recorded in Video Mode is finalised, it becomes DVD-Video.

◆ Audio CD

- An audio disc on which 44.1 kHz PCM Audio is recorded.
- Plays CD-DA format audio CD-R and CD-RW discs.
- The unit may not be able to play some CD-R or CD-RW discs due to the condition of the recording.

Downloaded From Disc-Player.com Samsung Manuals

◆ CD-R/-RW

- Use a 700MB (80 minutes) CD-R/-RW disc. If possible, do not use a 800MB (90 minutes) or above disc, as the disc may not play back.
- If the CD-R/-RW disc was not recorded as a closed session, you may experience a delay in the early playback time, all recorded files may not play.
- Some CD-R/-RW discs may not be playable with this unit, depending on the device which was used to burn them. For contents recorded on CD-R/-RW media from CDs for your personal use, playability may vary depending on contents and discs.

◆ DVD-R Disc Playback and Recording

- Once a DVD-R recorded in Video Mode is finalised, it becomes DVD-Video.
- You can record onto the available space on the disc and perform editing functions such as giving titles to discs and programmes and erasing programmes before finalising.
- When programming is erased from a DVD-R, that space does not become available. Once an area on a DVD-R is recorded on, that area is no longer available for recording, whether the recording is erased or not.
- It takes about 30 seconds for the unit to complete recording management information after recording finishes.
- This product optimizes the DVD-R for each recording. Optimizing is carried out when you start recording after inserting the disc or turning on the unit. Recording onto the disc may become impossible if optimizing is carried out too many times.
- Playback may be impossible in some cases due to the condition of recording.
- This unit can play back DVD-R discs recorded and finalised with a Samsung DVD video recorder. It may not be able to play some DVD-R discs depending on the disc and the condition of the recording.

◆ DVD-RW Disc Playback and Recording

- Recording and playback can be performed on DVD-RW discs in both the Video and VR Modes.
- Once a DVD-RW recorded in both the Video and VR Modes is finalised, you cannot perform additional recording.
- Once a DVD-RW recorded in Video Mode is finalised, it becomes DVD-Video.
- In both modes, playback can be performed before and after finalisation, but additional recording, deleting and editing can not be performed after finalisation.
- If you want to record the disc in VR Mode and then record in V Mode, be sure to execute Format. Be careful when executing Format because all the recorded data may be lost.
- A DVD-RW blank disc is initialised to VR Mode when first initialised.

◆ DVD-RAM Disc Playback and Recording

- Ensure that the recording mode is set to VR mode. Otherwise, this product will not be able to play the recording.
- You cannot play a DVD-RAM in most DVD components due to compatibility issues.
- Only DVD-RAM standard Version 2.0. discs can be played in this unit.
- DVD-RAM recorded on this unit may not work with other DVD components. To determine compatibility with these DVD-RAM discs, refer to the instruction manual for the player.
- For cartridge type DVD-RAM discs, remove the cartridge and use the disc only.

Downloaded From Disc-Player.com Samsung Manuals

Disc Copy

Contents Copy Specifications

Contents	HDD → DVD	DVD → HDD
Recorded Video Title	Supported	Supported
Copy Protected Title	Not supported	Not supported
Copy Once Title	Move (Deletes the Title in the HDD after copying)	Not supported
MP3	Supported	Supported
JPEG(photo)	Supported	Supported
DivX	Supported	Supported

Once "Copy Once programme" has been recorded on the DVD disc, this title cannot be copied to HDD anymore.

But "Copy Once programme" has been recorded on the HDD, this title can be copied to DVD-RW (VR mode) with CPRM or DVD-RAM.

When you copy MP3/JPEG/DivX files from HDD to DVD, only DVD-RW(V)/-R discs are available.

COPY PROTECTION

- Many DVD discs are encoded with copy protection.
- This product incorporates copyright protection technology that is protected by methods claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorised by Macrovision Corporation, is intended for home and other limited viewing uses only unless otherwise authorised by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Protection

This HDD & DVD Recorder can allow you to protect the contents of your discs, as described below.

- Programme-protected : See page 81 "Locking (Protecting) a Title"
- Disc-protected : See page 98 "Disc Protection"

❋ DVD-RAM/±RW/±R discs that are incompatible with the DVD-VIDEO format cannot be played with this product.

❋ For more information on DVD recording compatibility, consult your DVD-RAM/-RW/-R manufacturer.

❋ Use of poor quality DVD-RAM/-RW/-R discs may cause following unexpected problems including, without limitation, recording failure, loss of recorded or edited materials or damage to the HDD & DVD Recorder.

Disc Format

◆ Using MP3 disc

- CD-R/-RW, DVD-RAM/±RW/±R, HDD with MP3 files recorded with UDF, ISO9660 or JOLIET format can be playbacked.
- Only MP3 files with the ".mp3" or ".MP3" extension can be played.
- For MP3 files recorded with a VBR(Variable Bit Rates), from 32 Kbps to 320 Kbps, the sound may cut in out.
- Playable bit-rate range is from 56 Kbps to 320 Kbps.
- Each folder can have up to 500 items including files and sub folders.

◆ Using JPEG disc

- CD-R/-RW, DVD-RAM/±RW/±R, HDD recorded with UDF, ISO9660 or JOLIET format can be playbacked.
- Only JPEG files with the ".jpg" or ".JPG" extension can be displayed.
- Each folder can have up to 500 items including files and sub folders.
- MOTION JPEG and progressive JPEG are not supported.

◆ Using DivX disc

- Disc : CD-R/-RW, DVD-RAM/±RW/±R, HDD
- Video File with following extensions can be played. : .avi, .divx, .AVI, .DIVX
- DivX Video (Codec) Format : DivX 3.11 DivX 4.x DivX 5.x (without QPEL and GMC)
- DivX Audio (Codec) Format : MP3, MPEG1 Audio Layer 2, LPCM, AC3
- Supported subtitle file formats: .smi, .srt, .sub, .psb, .txt, .ass
- Each folder can have up to 500 items including files and sub folders.
- You cannot play back the disc that is larger than a 720 x 576 pixel resolution.

Downloaded From Disc-Player.com Samsung Manuals

Do not use the following discs!

- LD, CD-G, CD-I, CD-ROM and DVD-ROM discs should not be used in this product.

  [Note]

  Disc types that can be played : CD/CD-R/-RW/MP3/ JPEG/DVD-Video/DVD-RAM/±RW/±R.
  For a DVD-RW/-R disc, which has been recorded in Video Mode on another component, it can play only when finalised.

- Some commercial discs and DVD discs purchased outside your region may not be playable with this product. When these discs are played, either "No disc." or "Please check the regional code of the disc." will be displayed.
- If your DVD-RAM/±RW/±R discs is an illegal copy or is not in DVD video format, it may also not be playable.

◆ Disc compatibility

- High Speed Recording discs can be used in this unit.
- Not all brands of discs will be compatible with this unit.

Downloaded From Disc-Player.com Samsung Manuals

Contents

Getting Started

- Warning 2
- Precaution 3
  - Important Safety Instructions 3
  - Handling Cautions 3
  - Maintenance of Cabinet 3
  - HDD (Hard Disk Drive) 3
  - Disc Handling 4
  - Disc Storage 4
  - Disc Specifications 4
  - Disc Copy 6
- General Features 10
- Before reading the instruction manual 11
- How to use the HDD & DVD Recorder 11
- Unpacking 13
- Description 15
  - Front Panel 15
  - Rear Panel 16
  - Front Panel Display 16
  - Tour of the Remote Control 17

Connecting & Setting Up

- Connecting the HDD & DVD Recorder 18
- Other type of connecting the Video output cable 18
  - Case 1 : Connecting to a Video (Composite) output jack 19
  - Case 2 : Connecting to an S-Video output jack 19
  - Case 3 : Component Video output jacks 20
- Other type of connecting the Audio output cable 20
  - Case 1 : Connecting to your TV 20
  - Case 2 : Connecting to a stereo amplifier with AV output jacks 21
  - Case 3 : Connecting to an AV amplifier with a digital output jack 21
- Connecting HDMI/DVI to a TV 22
  - Case 1 : Connecting to a TV with HDMI Jack 22
  - Case 2 : Connecting to a TV with DVI Jack 22
- Connecting to AV 1 IN, AV 2 IN, DV input jack 23
  - Case 1 : Connecting a VCR, Set-Top Box(STB) or DVD player to the AV 1 IN jacks 23
  - Case 2 : Connecting a Camcorder to the AV 2 IN jacks 24
  - Case 3 : Connecting a Camcorder to the DV IN jack 24

System Setup

- On-Screen Menu Navigation 25
- Plug & Auto Setup 25
- Clock Set 26
  - Time Zone 26
  - Manual clock set 27
- Channel Set 27
  - Auto Setup 27
  - Digital Manual Setup 28
  - Analogue Manual Setup 28
  - Digital Channel List 29
  - Digital Favorite Channel 29
- Setting up the System Options 29
  - Auto Power Off Setting 30
  - Automatic Chapter Creator 30
  - EP Mode Time Setting 31
  - Anynet+ (HDMI CEC) 31
  - EZ Record 32
  - DVB-T Auto Subtitle 32
  - DivX(R) Registration 32
- Setting up the Language Options 33
- Setting up the Audio Options 33
- Setting up the Video Options 35
- Setting up the Parental Lock 38
  - If you forgot your password 38
  - Setting the Programme Grade 38
  - Setting the DVD Level 39
  - Changing the Password 39

DTV Functions

- Basic Functions 40
  - Display Screen 40
  - Select Audiotrack 40
  - Setting the Favorite Channel 41
  - Changing the Subtitle Language 41
  - Setting the Teletext OSD 41
- Guide 42
  - Guide Timer Recording 42

Downloaded From Disc-Player.com Samsung Manuals

Playback

- Region code (DVD-Video only) 43
- Logos of Discs that can be played 43
- Disc types that can be played 43
- Playing a Disc 44
- Using the Disc Menu & Title Menu 45
- Using the playback related buttons 46
- Using the INFO button 48
- Selecting the Subtitle Language 48
- Selecting the Soundtracks & Audio Channels 49
- Changing the Camera Angle 49
- Repeat Play 50
- Zooming-In 51
- Using Markers 52
- Using the Bookmarks 53
- Playing an Audio CD/MP3 54
- Viewing a Picture 59
- Playing a DivX 61

Recording

- Recordable Discs 63
- Recording Formats 64
- Recording Mode 65
- Unrecordable pictures 66
- Recording immediately 67
- Copying from a Camcorder 69
- Making a One Touch Recording (OTR) 70
- Simultaneous Recording and Playback 71
- Time Shift function as a live signal 72
- Making a Timer Recording 73
  - Editing the Scheduled List 75
  - Adding a Scheduled List 75
  - Deleting a Scheduled List 76
- Using the G-Code Feature 77
- G-Code Extended 78
- Go To Recorded List 78

Editing

- Basic Editing (Title List) 80
  - Playing the Title 80
  - Renaming (Labeling) a Title 80
  - Locking (Protecting) a Title 81
  - Deleting a Title 82
  - Splitting a Section of a Title (Split) 83
  - Deleting a Section of a Title (Partial Delete) 84
- Using the Sort function (Title List) 85
- Navigation Menu 85
- Select Contents 86
- Advanced Editing (Playlist) 87
  - Creating a Playlist 87
  - Playing Entries in the Playlist 88
  - Renaming a Playlist Entry 88
  - Editing a Scene for the Playlist 89
  - Deleting a Playlist Entry from the Playlist 91
  - Using the Sort (Playlist) 92
- Copying from HDD to DVD 92
- Copying from DVD to HDD 94
- Copying MP3, JPEG or DivX 95
  - File Copy 95
  - Folder Copy 95
- Changing the name of Music/Photo/DivX file 97
- Disc Manager 98
  - Editing the Disc Name 98
  - Disc Protection 98
  - Delete All Title Lists 99
  - Delete All Title Lists/DivX Lists /Music Lists/Photo Lists 99
  - Formatting a Disc 100
  - Finalising a Disc 101
  - Unfinalising a Disc (V/VR mode) 102

Reference

- Troubleshooting 103
- Specifications 106

Downloaded From Disc-Player.com Samsung Manuals

General Features

This unit allows you to record and playback high quality digital video on DVD-RAM/-RW/-R discs or on the HDD. You can also edit digital images on DVD-RAM/-RW discs or HDD. (DVD+RW/+R discs can be played, but cannot be recorded.)

HDD Recording

• DVD-SH853
You can record up to Approx. 264 hours of video (in EP 8Hr mode) on the internal 160 GB (gigabyte) hard disk (HDD).

• DVD-SH855
You can record up to Approx. 421 hours of video (in EP 8Hr mode) on the internal 250 GB (gigabyte) hard disk (HDD).

With both recordable DVD and a high-capacity HDD in the same recorder, you have the flexibility to keep recordings on the HDD for quick access anytime, or record to DVD for archiving or playing on other DVD players.

Copy between HDD and DVD

You can copy recordings from the HDD to recordable DVD, or from recordable DVD to the HDD.
You can only copy in the same record mode as source title.

Simultaneous Recording and Playback

Playback and recording for both the DVD and the built-in hard disk drive (HDD) are completely independent. For example you can record a broadcast programme to either a recordable DVD or the HDD, while watching another recording you already made on the same DVD or on the HDD.

High quality digital audio and video recording and playback

You can record up to approximately 16-hours of video on a double side 9.4GB DVD-RAM disc, up to 15-hours on a dual-layer 8.5GB DVD-R disc, and up to 8-hours on a 4.7GB DVD-RAM/-RW/-R disc, depending on the recording mode.

Selectable Recording Mode

You can set your HDD & DVD Recorder to one of four different recording speeds, each varying in recording quality and length. EP (6Hr or 8Hr) mode yields the most recording time, LP & SP modes provide less recording time with higher quality recording, XP mode gives you the highest quality recording.
The dual layer DVD-Rs have approximately double the capacity of single layer DVD-Rs. (See page 43)

Automated Quality Adjustment for Timer Recording

If FR mode is selected, the video quality is adjusted automatically so that all video for the scheduled time can be recorded onto the free disc space.
(See page 73)

Creating a DVD video title using DVD-RW/-R disc

With the HDD & DVD Recorder, you can create your own DVD Video titles on 4.7 GB DVD-RW/-R discs.

Copying data from a digital camcorder using a DV input jack

Record DV Device video onto HDD and DVD-RAM/-RW/-R discs using the DV input jack (IEEE 1394-4pin/4pin).
(See page 69)

High quality progressive scan

Progressive scanning provides high resolution and flicker free video. The 10-bit 54-MHz DAC and 2D Y/C Separating Circuitry provides the highest image playback and recording quality. (See page 37)

DivX Certification

DivX, DivX Certified, and associated logos are trademarks of DivX Networks, Inc and are used under licence.

HDMI (High Definition Multimedia Interface)

HDMI reduces picture noise by allowing a pure digital video/audio signal path from the HDD & DVD Recorder to your TV.
This HDD & DVD Recorder supports 576P, 720P and 1080i.

Anynet+(HDMI CEC)

Anynet+ is a function that can be used to operate the recorder using a Samsung TV remote control, by connecting the HDD & DVD Recorder to a SAMSUNG TV using an HDMI Cable. (This is only available with SAMSUNG TVs that support Anynet+.)

EZ Record Mode

This function allows you initialise and Finalise a disc automatically. (See page 32)

EPG functions

EPG is an Advanced Electronic Programme Guide. With a Remote Control Unit, you can operate full function.
It has a Auto and Manual Scan facility and Channel Organizing (programmable) facility.

Downloaded From Disc-Player.com Samsung Manuals

Before reading the instruction manual

Make sure to check the following terms before reading the instruction manual.

Icons that will be used in manual

Icon	Term	Definition
HDD	HDD	This involves a function available on the HDD.
DVD-VIDEO	DVD	This involves a function available on DVD or DVD±R/-RW(V) discs that have been finalised.
DVD-RAM	RAM	This involves a function available on DVD-RAM.
DVD-RW	-RW	This involves a function available on DVD-RW.
DVD-R	-R	This involves a function available on DVD-R.
DVD+RW	+RW	This involves a function available on DVD+RW.
DVD+R	+R	This involves a function available on DVD+R.
CD	CD	This involves a function available on a data CD (CD-R or CD-RW).
JPEG	JPEG	This involves a function available on CD-R/-RW, DVD±R/±RW/-RAM discs or HDD.
MP3	MP3	This involves a function available on CD-R/-RW, DVD±R/±RW/-RAM discs or HDD.
DivX	DivX	This involves a function available on CD-R/-RW, DVD±R/±RW/-RAM discs or HDD.
	Caution	This involves a case where a function does not operate or settings may be cancelled.
	NOTE	This involves tips or instructions on the page that help each function operate.
	One-Touch button	A function that can be operated by using only one button.

About the use of this instruction manual

1) Be sure to be familiar with Safety Instructions before using this product. (See pages 2~7)
2) If a problem occurs, check the Troubleshooting. (See pages 103~105)

Copyright

©2007 Samsung Electronics Co.
All rights reserved; No part or whole of this instruction manual may be reproduced or copied without the prior written permission of Samsung Electronics Co.

How to use the HDD & DVD Recorder

Step 1 : Select the disc type or HDD

Please check available disc type before recording.

HDD DVD RAM DVD RW DVD R

(DVD+RW/DVD+R discs can be played, but cannot be recorded.)

If you want to repeatedly record on the same disc or you want to edit the disc after recording, select a rewritable DVD-RW or DVD-RAM type disc. If you want to save a recording without any changes, choose a non-rewritable DVD-R. You can record files directly to the built-in HDD or edit a recorded file.

Step 2 : Format the disc to start recording

Unlike a VCR, the HDD & DVD Recorder starts formatting when an unused disc is inserted. This is required for the preparation of recording on a disc.

Using the HDD

Formatting unnecessary.

Using a DVD-RAM

This type of disc can be formatted in DVD-Video Recording format (VR mode). You can edit recorded images and create a playlist in a specific sequence according to your requirements.

Using a DVD-RW

This type of disc can be formatted in either DVD-Video format (V mode) or DVD-Video Recording format (VR mode). For an unused disc, a message that asks whether to initialise a disc or not. If you select "DVD-VR" or "DVD-V", initialising will be started. You can play a Video mode disc on various DVD components. A VR mode disc allows more varied editing.

Downloaded From Disc-Player.com Samsung Manuals

Using a DVD-R

Formatting disc is unnecessary and only V Mode Recording is supported. You can play these type of discs on various DVD components only when they have been finalised.

- You can only use either the VR or Video mode on a DVD-RW, but not both at the same time.
- You can format a DVD-RW to V or VR mode using **Disc Manager**. It should be noted that the disc's data will be lost when changing formats.

Step 3 : Recording

There are two different recording methods, Direct Recording and Timer Recording. Timer recording is classified as follows:

Recording mode : XP (high quality mode), SP (standard quality mode), LP (long recording mode), and EP (extended mode) according to the recording mode.
When recording is set in the FR mode, the best quality picture is recorded with regards to the remaining time on the disc.

Step 4 : Playing

You can select the title you want to play in a displayed menu and then immediately start playback.

A DVD consists of sections, called titles, and sub-sections, called chapters.

During recording, a title is created between two points where you start and stop recording.
Chapters will be created automatically when you finalise recording on DVD-RW/-R discs in Video mode.
The chapter's length (interval between chapters) varies according to the recording mode.

Step 5 : Editing a recorded disc

Editing on discs is easier than conventional video tapes. The HDD & DVD Recorder supports many different edit functions, possible only with DVDs and HDD.
With a simple and easy edit menu, you can operate various edit functions, such as delete, copy, rename, lock, etc., on a recorded title.

Creating a playlist (DVD-RAM/-RW in VR mode, HDD)
With this HDD & DVD Recorder, you can create a new playlist on a disc and edit it without the original, pre-existing recording.

Step 6 : Finalising & Playing on other DVD components

To play your DVD on other DVD components, finalising may be necessary. First, finish all editing and recording operations, then finalise the disc.

When using a DVD-RW disc in VR Mode
DVD discs recorded in VR mode can only be played back in DVD recorders, not players.

When using a DVD-RW disc in Video Mode
The disc should be finalised first to enable playback on anything other than this HDD & DVD Recorder. No more editing or recording can be made on the disc once it has been finalised.
To enable recording on the disc again, the disc must be unfinalised.

When using a DVD-R disc
You should finalise the disc to play it on a component other than this HDD & DVD Recorder. You cannot edit or record on the disc once it has been finalised.

- You can finalise the disc automatically using EZ Record function. (See page 32)

Downloaded From Disc-Player.com Samsung Manuals

Unpacking

Accessories

Check for the supplied accessories below.


Video/Audio Cable


RF Cable for TV

Remote Control

Batteries for Remote Control (AAA Size)


Instruction Manual


Quick Guide

Preparing the Remote Control

Install Batteries in the Remote Control

- Open the battery cover on the back of the remote control.
- Insert two AAA batteries. Make sure that the polarities (+ and –) are aligned correctly.
- Replace the battery cover.

If the remote does not operate properly :

- Check the polarity + – of the batteries (Dry-Cell)
- Check if the batteries are drained.
- Check if remote sensor is blocked by obstacles.
- Check if there is any fluorescent lighting nearby.

Dispose of batteries according to local environmental regulations. Do not put them in the household trash.



To determine whether your television is compatible, follow the instructions below.

1. Switch your television on.
2. Point the remote control towards the television.
3. Press and hold the **TV STANDBY/ON** button and enter the two-figure code corresponding to the brand of your television, by pressing the appropriate number buttons.

Downloaded From Disc-Player.com Samsung Manuals

Controllable TV Codes

BRAND	BUTTON
SAMSUNG	01, 02, 03, 04, 05, 06, 07, 08, 09
AIWA	82
ANAM	10, 11, 12, 13, 14, 15, 16, 17, 18
BANG & OLUFSEN	57
BLAUPUNKT	71
BRANDT	73
BRIONVEGA	57
CGE	52
CONTINENTAL EDISON	75
DAEWOO	19, 20, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34
EMERSON	64
FERGUSON	73
FINLUX	06, 49, 57
FORMENTI	57
FUJITSU	84
GRADIENTE	70
GRUNDIG	49, 52, 71
HITACHI	60, 72, 73, 75
IMPERIAL	52
JVC	61, 79
LG	06, 19, 20, 21, 22, 78
LOEWE	06, 69
LOEWE OPTA	06, 57
MAGNAVOX	40
METZ	57
MITSUBISHI	06, 48, 62, 65
MIVAR	52, 77
NEC	83
NEWSAN	68
NOBLEX	66
NOKIA	74
NORDMENDE	72, 73, 75
PANASONIC	53, 54, 74, 75
PHILIPS	06, 55, 56, 57
PHONOLA	06, 56, 57
PIONEER	58, 59, 73, 74
RADIOLA	06, 56
RADIOMARELLI	57
RCA	45, 46
REX	74
SABA	57, 72, 73, 74, 75
SALORA	74
SANYO	41, 42, 43, 44, 48
SCHNEIDER	6
SELECO	74
SHARP	36, 37, 38, 39, 48
SIEMENS	71
SINGER	57
SINUDYNE	57
SONY	35, 48
TELEAVA	73
TELEFUNKEN	67, 73, 75, 76
THOMSON	72, 73, 75
THOMSON ASIA	80, 81
TOSHIBA	47, 48, 49, 50, 51, 52
WEGA	57
YOKO	6
ZENITH	63

Result : If your television is compatible with the remote control, it will switch off.
It is now programmed to operate with the remote control.

- If several codes are indicated for your television brand, try each one in turn until you find one that works.
- If you replace the remote control's batteries, you must set the brand code again.

Then you can control the television using the following buttons after pressing the TV button.

Button	Function
TV STANDBY/ON	Used to switch the television on and off.
INPUT SEL.	Used to select an external source.
TV VOL (+ –)	Used to adjust the volume of the television.
PROG (∧∨)	Used to select the desired channel.
TV MUTE	Used to toggle the sound on and off.
Number	Used to input number directly.

- The functions listed above will not necessarily work on all televisions. If you encounter problems, operate the television directly.

Downloaded From Disc-Player.com Samsung Manuals

Description

Front Panel



1. **STANDBY/ON button**
   Turns the HDD & DVD Recorder on and off.
2. **DISC TRAY**
   Opens to accept a disc.
3. **OPEN/CLOSE button**
   Opens and closes the disc tray.
4. **DISPLAY**
   Displays the playing status, time, etc.
5. **AV 2 INPUT**
   Connect external equipment.
6. **DV-INPUT**
   Connect external digital equipment with a DV jack. (such as a camcorder)
7. **P.SCAN button**
   Selects the progressive scan mode.
8. **DVD button**
   Select DVD mode.
9. **HDD button**
   Select HDD mode.
10. **PROG buttons**
    Select TV preset Channels. Same as PROG button on the remote control.
11. **REC button**
    Starts recording.
12. **STOP button**
    Stops disc playback.
13. **PLAY/PAUSE button**
    Plays a disc or pauses playback.
14. **SEARCH/SKIP buttons**
    Goes to the next title/chapter/track or goes back to the previous title/chapter/track.

Downloaded From Disc-Player.com Samsung Manuals

Rear Panel



Fan
The fan always revolves when the power is on. Ensure a minimum of 10 cm clear space on all sides of the fan when installing the product.

1. **In from aerial connector**
2. **Out to TV connector**
3. **AV 1 AUDIO IN**
   Connects the output of external equipment using an audio cables.
4. **AV 1 VIDEO IN**
   Connects the output of external equipment using an video cables.
5. **COMPONENT VIDEO OUT**
   Connects to equipment having Component video input.
6. **HDMI OUT**
7. **AUDIO OUT**
   Connects to the audio input of external equipment using audio cables.
8. **VIDEO OUT**
   Connects the input of external equipment using a Video cable.
9. **S-VIDEO OUT**
   Connects the input of external equipment using an S-Video cable.
10. **DIGITAL AUDIO OUT(COAXIAL)**
    Connects to an amplifier having a digital coaxial audio input jack.
11. **DIGITAL AUDIO OUT(OPTICAL)**
    Connects to an amplifier having a digital optical audio input jack.

- The Antenna connection does not pass the output signal of the DVD.
  To watch DVD/HDD playback your TV, you must connect audio/video.

Front Panel Display



1. Lights when a disc is loaded.
2. Lights in the record mode.
3. Lights when a HDD/DVD is selected.
4. Lights when a DVD-RAM/±RW/±R disc is loaded.
5. Playing time/clock/current status indicator.
6. Lights in the progressive scan mode.
7. Lights to indicate the timer record mode.

Downloaded From Disc-Player.com Samsung Manuals

Tour of the Remote Control

Your HDD & DVD Recorder remote control will work with Samsung televisions and compatible brands.



1. **DVD button**
   Press this to operate DVD.
2. **TV button**
   Press this to operate TV.
3. **STANDBY/ON button**
4. **NUMBER buttons**
5. **TV/DVD button (Not available)**
6. **TV MUTE button**
   In TV mode, this operates as sound mute.
7. **REVERSE/FORWARD SKIP buttons**
   Press to skip backwards or forwards.
8. **STOP button**
   Press to stop a disc.
9. **REVERSE/FORWARD SEARCH buttons**
   Press to search a disc backwards or forwards.
10. **TV VOL button**
    TV volume adjustment.
11. **MENU button**
    Brings up the HDD & DVD Recorder's setup menu.
12. **OK/DIRECTION buttons (▲▼◄ ► buttons)**
13. **i (INFO) button**
    Press to display the programme information box in the screen when you use DTV.
    Allows access to common functions of the HDD & DVD Recorder. (See page 48.)
14. **TITLE LIST/DISC MENU button**
    Use this to enter the View Recording list/disc menu.
15. **SUBTITLE/RED(A) button :**
    When you use DTV, press this button to select the subtitle.
    Press this to switch DVD's subtitle language.
16. **REC MODE/GREEN(B) button**
    Use this to set the desired recording time and picture quality. (XP/SP/LP/EP).
17. **GUIDE button**
    Press this to switch programme guide.
18. **REC button**
    Use to make a recording on HDD/DVD-RAM/-RW/-R discs.
19. **TV/RADIO/MARKER button**
    In **DTV** mode, press this to switch TV or Radio mode.
    Use this to bookmark a position while playing a disc.
20. **HDD button**
    Press this to operate HDD.
21. **INPUT SEL button**
    Select input signal in external input mode (PROG, AV1, AV2 or DV input)
22. **OPEN/CLOSE button**
    To open and close the disc tray.
23. **TV STANDBY/ON button**
24. **COPY**
    Press this when you copy DVD to HDD and vice-versa.
    To start copying, press the **COPY** button on the title list screen or press the **COPY** button during the playback.
25. **AUDIO button**
    Use this to access various audio functions on a disc. (DVD mode)
26. **PLAY/PAUSE button**
    Press to play/pause a disc.
27. **PROG button**
    Use this to select a TV programme.
28. **DTV/ANALOG button**
    Select Digital/Analogue broadcasting.
29. **RETURN button**
30. **EXIT button**
31. **PLAY LIST/TITLE MENU button**
    Use this to return to the Title menu, or to view the recorded files list.
32. **ALT/YELLOW(C) button**
    When you use DTV, press this button to select the Audio track.
33. **FAV LIST/BLUE(D) button**
    When you use DTV, press this button to switch between favorit list.
34. **TEXT button**
    When you use DTV, press this button to select the Teletext OSD.
35. **REC PAUSE/TIME SHIFT button**
    Use this to pause during recording.
    In HDD mode, use this to operate Time shift function.
36. **TIMER/REPEAT button**
    Press to directly enter the Timer Recording Mode menu.
    Allows you to repeat a title, chapter, track or disc.

Downloaded From Disc-Player.com Samsung Manuals

Connecting & Setting Up

Connecting the HDD & DVD Recorder

1. Disconnect the aerial cable from your TV and connect it to RF IN (FROM ANT.) connector on the rear panel of the HDD & DVD Recorder.
2. Connect RF OUT (TO TV) connector of the HDD & DVD Recorder and the aerial input of your TV using the supplied aerial cable.
3. Use the Video/Audio Cable to connect ANALOG AUDIO OUT(R/L)/VIDEO OUT jacks on the HDD & DVD Recorder to the Audio &Video jacks on the TV.
4. Plug in the HDD & DVD Recorder and TV
5. Turn on the HDD & DVD Recorder and TV.
6. Press the **INPUT SEL.** button on your TV remote control until the Video signal from the HDD & DVD Recorder appears on the TV screen.



- The RF cable connection of this product sends only signals of TV.You must connect Audio/Video cables to watch a DVD from your HDD & DVD Recorder.
- Power off HDD & DVD Recorder, then you can watch programmes received through 2 RF cable.

Other type of connecting the Video output cable

There are several ways to output video signal. Select one of the following video connecting that best suits you below.

- **Case 1** : Connecting to a Video (Composite) output jack
- **Case 2** : Connecting to an S-Video output jack
- **Case 3** : Component Video output jacks

S-Video, Component video and Progressive Output Modes

- S-Video and Component video output are available only if your TV supports S-Video input or Component video input, respectively. If S-Video or Component video output does not work, check the TV connections and the TV input selection settings.
- Compared to standard interlaced video, progressive scan doubles the amount of video lines fed to your TV, resulting in a more stable, flicker-free, clear image than interlaced video. This is only available with TVs that support progressive scan.
- Progressive Scan Output (576P)
  Consumers should note that not all high definition television sets are fully compatible with this product and may cause artifacts to be displayed in the picture, in case of 576 progressive scan picture problems, It is recommended that the user switch the connection to the 'standard definition' output. If there are questions regarding our TV set compatibility with this model 576P HDD & DVD Recorder, please contact our customer service centre.

Downloaded From Disc-Player.com Samsung Manuals

Case 1 : Connecting to a Video (Composite) output jack

1. Connect a video (Yellow) cable between the VIDEO (yellow) OUT jack on HDD & DVD Recorder and VIDEO (yellow) INPUT jack on your TV (or AV amplifier).
   • You will enjoy regular quality images.
2. Connect audio cables (white and red) between the AUDIO OUT jacks on the HDD & DVD Recorder and AUDIO IN jacks on TV (or AV amplifier).
   (See pages 20~21)



Case 2 : Connecting to an S-Video output jack

1. Connect an S-Video cable (not included) between the S-VIDEO OUT jack on HDD & DVD Recorder and S-VIDEO INPUT jack on your TV (or AV amplifier).
   • You will enjoy high quality images.
2. Connect audio cables (white and red) between the AUDIO OUT jacks on HDD & DVD Recorder and AUDIO IN jacks on TV (or AV amplifier).
   (See pages 20~21)



Downloaded From Disc-Player.com Samsung Manuals

Case 3 : Component Video output jacks

1. Connect Component video cables(not supplied) between the COMPONENT OUT(Y, P_B, P_R) jacks on HDD & DVD Recorder and COMPONENT IN(Y, P_B, P_R) jacks on your TV.
   - You will enjoy high quality and accurate colour reproduction images.
2. Connect audio cables (white and red) between the AUDIO OUT jacks on the HDD & DVD Recorder and AUDIO IN jacks on TV (or AV amplifier). (See pages 20~21).
3. After connecting, refer to the page 35.



- Make sure that the colour coded connections match. The Y, P_B, P_R component output jacks of your HDD & DVD Recorder must be connected to the exact corresponding component input jacks on your TV.
- Progressive setting is only available when the HDD & DVD Recorder is connected to your TV using component cables. (See page 37)

Other type of connecting the Audio output cable

There are several ways to connect your HDD & DVD Recorder.
Select the audio connection that best suits you below.

- **Case 1** : Connecting to your TV
- **Case 2** : Connecting to a stereo amplifier with AV output jacks
- **Case 3** : Connecting to an AV amplifier with a digital output jack

Manufactured under licence from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories.

"DTS" and "DTS Digital Out" are trademarks of DTS, Inc.

Case 1 : Connecting to your TV

If your TV has audio input jacks, use this connection.



Downloaded From Disc-Player.com Samsung Manuals

Case 2 : Connecting to a stereo amplifier with AV output jacks

If your stereo amplifier only has AUDIO INPUT jacks (L and R), use the AUDIO OUT jacks



Case 3 : Connecting to an AV amplifier with a digital output jack

If your AV amplifier has a Dolby Digital, MPEG2 or DTS decoder and a digital input jack, use this connection. To enjoy Dolby Digital, MPEG2 or DTS sound, you will need to set up the audio settings. According to your amplifier, connect to an optical cable or a coaxial cable.
(See pages 33~34)



Downloaded From Disc-Player.com Samsung Manuals

Connecting HDMI/DVI to a TV

If your TV has a HDMI/DVI input, connect HDMI/DVI Adapter cable to a TV. You will enjoy the best quality images and sounds.

- **Case 1** : Connecting to a TV with HDMI Jack
- **Case 2** : Connecting to a TV with DVI Jack

Case 1 : Connecting to a TV with HDMI Jack

- Using the HDMI cable connect the HDMI OUT jack on the rear of the HDD & DVD Recorder to the HDMI IN jack of your TV.
- Press the input selector on your TV remote control until the HDMI signal from the HDD & DVD Recorder appears on your TV screen.



Case 2 : Connecting to a TV with DVI Jack

- Using the DVI Adapter cable (not supplied), connect the HDMI OUT jack on the rear of the HDD & DVD Recorder to the DVI IN jack of your TV.
- Using the audio cables, connect the AUDIO (red and white) OUT jacks on the rear of the HDD & DVD Recorder to the AUDIO (red and white) IN jacks of your TV. Turn on the HDD & DVD Recorder and TV.
- Press the input selector on your TV remote control until the DVI signal from the HDD & DVD Recorder appears on your TV screen.



- To use HDMI cable, make the Audio/Video connection before plugging in the power cord or after finishing the "Plug & Auto Setup." Do not connect the HDMI cable while the "Plug & Auto Setup" is progressing.
- Progressive scan automatically activates when HDMI is connected.
- If your TV does not have Bitstream decoder, you must set the digital audio output to PCM in order to watch through the HDMI output.
(See pages 34~35)
- Depending on the HDMI device (TV/HDMI Receiver) you use, audio may not be supported. If TV/HDMI Receiver does not support Dolby digital, Audio output is not available when you set Digital output as 'Bitstream' in Audio setup menu. In this case, set the digital audio output to PCM. If TV/HDMI Receiver does not support DTS, Audio output is not available when you play disc in DTS format.
- You can switch from the HDMI output to other output only in stop mode.
- If you use an HDMI cable to connect a Samsung TV to the HDD & DVD Recorder, you can operate the recorder using the TV remote control.
(This is only available with SAMSUNG TVs that support Anynet+(HDMI-CEC).)
(See page 31)
- Please check the Anynet+ logo (If your TV has an Anynet+ logo, then it supports Anynet+ function.)

Downloaded From Disc-Player.com Samsung Manuals

- **HDMI (High Definition Multimedia Interface)**
  HDMI is an interface to enable the digital transmission of video and audio data with just a single connector. Since HDMI is based on DVI, it is completely compatible with DVI. The only difference between HDMI and DVI is that HDMI supports multi-channel audio. Using HDMI, the HDD & DVD Recorder transmits a digital video and audio signal and displays a vivid picture on a TV having an HDMI input jack.
- **HDMI connection description**
  HDMI connector - Both uncompressed video data and digital audio data (LPCM or Bit Stream data).
  - Though the HDD & DVD Recorder uses a HDMI cable, the HDD & DVD Recorder outputs only a pure digital signal to the TV.
  - If TV does not support HDCP (High -bandwidth Digital Content Protection), snow noise appears on the screen.
- **Why does Samsung use HDMI?**
  Analog TVs require an analog video/audio signal. However, when playing a DVD, the data transmitted to a TV is digital. Therefore either a digital-to-analog converter (in the HDD & DVD Recorder) or an analog-to-digital converter (in the TV) is required. During this conversion, the picture quality is degraded due to noise and signal loss. HDMI technology is superior because it requires no D/A conversion and is a pure digital signal from the HDD & DVD Recorder to your TV.
- **What is the HDCP?**
  HDCP (High-bandwidth Digital Content Protection) is a system for protecting DVD content outputted via HDMI from being copied. It provides a secure digital link between a video source (PC, DVD. etc) and a display device (TV, projector. etc). Content is encrypted at the source device to prevent unauthorized copies from being made.

Connecting to AV 1 IN, AV 2 IN, DV input jack

This allows you to connect your HDD & DVD Recorder to other external devices and view or record their outputs.

- **Case 1** : Connecting a VCR, Set-Top Box(STB) or DVD player to the AV 1 IN jacks
- **Case 2** : Connecting a Camcorder to the AV 2 IN jacks
- **Case 3** : Connecting a Camcorder to the DV IN jack

Case 1 : Connecting a VCR, Set-Top Box(STB) or DVD player to the AV 1 IN jacks

Connecting a VCR or external device to AV 1 IN jacks of the HDD & DVD Recorder. You can record from connected equipment (VCR, STB or DVD).



- You can also use the AV 2 IN jacks on the front panel of the HDD & DVD Recorder.
- Copy protected content cannot be recorded.

Downloaded From Disc-Player.com Samsung Manuals

Case 2 : Connecting a Camcorder to the AV 2 IN jacks

You can also use the AV 2 IN jacks on the front panel of the HDD & DVD Recorder.
You can record from connected equipment, such as a camcorder.
When an input source is inserted into AV 2 while viewing TV, the input will be switched to AV 2 automatically. If the input is not selected automatically, use **INPUT SEL.** button to select proper input.



Case 3 : Connecting a Camcorder to the DV IN jack

If your digital camcorder has a DV output jack, connect it to the DV input jack of your HDD & DVD Recorder.



- If the input is not selected automatically, use **INPUT SEL.** button to select proper input.

Downloaded From Disc-Player.com Samsung Manuals

On-Screen Menu Navigation

The on-screen menus allow you to enable or disable various functions on your HDD & DVD Recorder.
Press the MENU button to open the on-screen menu and then use the following buttons to navigate through the on screen menus.

1. ▲▼, ◄► buttons
   Press these buttons on the remote control to move the selection bar ▲▼, ◄► to cycle through the menu options.
2. **OK** button
   Press this button on the remote control to confirm any new settings.
3. **RETURN** button
   Press this button on the remote control to return to the Previous menu screen displayed or to exit the on-screen menu.
4. **EXIT** button
   Press this button to exit the on-screen **menu**.







Plug & Auto Setup

Your HDD & DVD Recorder will automatically set itself up when it is plugged in for the first time. TV stations and clock will be stored in memory. The process takes a few minutes. Your HDD & DVD Recorder will then be ready for use.

1. Connect the RF cable as indicated on page 18.
   (Connecting Your HDD & DVD Recorder to the TV Using the RF Cable.)
   To use HDMI cable (not supplied), make the Audio/Video connection before plugging in the power cord or after finishing the "Plug & Auto Setup." Do not connect the HDMI cable while the "Plug & Auto Setup" is progressing.
2. Plug the HDD & DVD Recorder into the mains. "AUTO" in the front panel display flickers.
3. Press the **OK** or ► button, then **Language** option display.
   Press the ▲▼ buttons to select the desired language option, then press the **OK** button.
4. Press the **OK** or ► button, then **Time Zone** option display.
   Press the ◄► buttons to select the desired time zone option.
   Press the ▲▼ buttons to select **OK**, then press the **OK** button.

Downloaded From Disc-Player.com Samsung Manuals







5. Press the ▼ button to select **OK**, then press the **OK** button.
   Digital auto scan will be started.
6. After auto channel scan is completed, the message " Your digital receiver found" will be displayed.
7. Press the **OK** button.
   Analogue auto scan will be started.

- Now, HDD & DVD Recorder is ready for use. Function for "Plug & Auto Setup" is fixed already. So if you want to change this fixed one, you can change it by Presetting the Stations in OSD "Channel Set - Manual Setup" menu. (See pages 27~28)
- Auto setup function can be performed by pressing **STOP** (■) on the unit continuously for 5 seconds or more during power off with no disc inserted.

8. Check the date and time.
   - If it is : Correct, press **OK** button then the date and time will be saved. If you don't press the **OK** button, the date and time will be saved automatically after 5 seconds.
   - If it is : Incorrect, input correct **Month, Day, Year, Hour** or **Minute** using ▲▼, ◄► buttons or number buttons. Press **OK** button then the date and time will be saved. When you need to change clock setting, you can set up it manually.

Clock Set

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **Clock Set**, then press the **OK** or ► button.

Time Zone

To setup, follow steps 1~3

4. Press the ▲▼ buttons to select **Time Zone**, then press the **OK** or ► button. Select the time zone of your area using the ◄ ► buttons, then select **OK** using ▲▼ button.

◆ **GMT (Greenwich Mean Time) Table**

Country	GMT	City
Australia	GMT+8	WA
	GMT+9:30	NT, SA
	GMT+10	ACT, NSW, TAS, VIC

Downloaded From Disc-Player.com Samsung Manuals

Manual clock set



To setup, follow steps 1~3 in page 26.

4. Press the ▲▼ buttons to select **Manual Clock Set**, then press the **OK** or ► button.
   Use the ▲▼◄ ► buttons to input Time, Date or Year.
   Use number buttons to input clock data directly.
5. Press the **OK** button, then the date and time will be saved.
   If you don't press the **OK** button, it will not be saved.

■ The DVD Recorder automatically sets the clock according to the time signal broadcast from Digital channel.
If you get the exact time, please select Time Zone properly.

Channel Set

This menu consist of 5 sub-menus (Digital Channel List, Digital Favorite Channel, Auto Setup, Digital Manual Setup, Analogue Manual Setup).

Auto Setup

This function allows you to download of the channels automatically from the programmed load.

1. Press the **MENU** button.
2. Press the ▲▼ buttons to select **Channel**, then press **OK** or ► button.
3. Press the ▲▼ buttons to select **Auto Setup**, then press **OK** or ► button.
4. Press the ▲▼◄► buttons to select **desired options**.



(Channel Type : Digital)





(Channel Type : Analogue)



- **Channel type** : Press the ◄► buttons to select Digital, Analogue or All. (If you select Analogue, you can not select the Scan Mode, Start frequency and End frequency.)
- **Scan Mode** : - Only Free : Receives signals except for the scrambled signal.
  - All : Receives signals including the scrambled signal.
- **Start frequency/End frequency** : It is changed automatically when the country is selected.

5. Press the ▲▼ button to select **Start**, then press **OK** button.
   Auto Scan will be started.

■ You can select RADIO mode by pressing the **TV/RADIO** button on the remote control.
This button used to toggle the TV and RADIO mode.

Downloaded From Disc-Player.com Samsung Manuals

Digital Manual Setup





To tune-in new channels, the HDD & DVD Recorder has been provided with the option Manual Scan where the channel data can be entered by user.

To setup, follow steps 1~2 in page 27.

3. Press the ▲▼ buttons to select **Digital Manual Setup**, then press **OK** or ► button.

4. Select the **Channel Number** which you want to find using ◄► buttons.
   Select **Frequency** and input the Frequency of the channel you want to find by pressing the number button.
   Select **Bandwidth** which you want to find using ◄► buttons.
   When the valid frequency is input, the bandwidth is selected automatically. You can select the value of 6,7 or 8 MHz. After select option. Press **OK** button to start the scanning process.

Analogue Manual Setup





To setup, follow steps 1~2 in page 27.

3. Press the ▲▼ buttons to select **Analogue Manual Setup**, then press **OK** or ► button.

4. Press the ▲▼ buttons to select a **PR**(programme) you wish to edit, delete, or swap, then press the **COLOUR** button.
   Select **Edit**, **Delete** or **Swap**.
   - **In case of Edit (RED(A) button)** : You can add or edit PR(programme) information. After change PR informations (**CH.**, **Name**, **MFT, System**), select **Save**, then press the **OK** button.
     - **CH** : Tune the channel using ◄► buttons.
     - **Name** : Display station name automatically detected in broadcasting signal. If not detected, you can edit name by using ▲▼◄► buttons.
     - **MFT(Manual Frequency Tunning)** : You can tune up the channel frequency better using ◄► buttons.
     - **System** : You can select broadcasting system of the receivable channel (B/G or B/B)
   - **In case of Delete (GREEN(B) button)** : the channel information of selected PR(programme) will be removed.
   - **In case of Swap (YELLOW(C) button)** : You can swap the channel information of two PR(programme). For example, if you wish to swap PR2 and PR5, select swap at PR2, then press the **OK** button at PR5.

Downloaded From Disc-Player.com Samsung Manuals

Digital Channel List

This function is possible in DVB-T mode only.
This function is used to edit the favorite channel list or delete the channel.

To setup, follow steps 1~2 in page 27.

3. Press the ▲▼ buttons to select **Digital Channel List**, then press **OK** or ► button.
4. To edit the current channel to the Digital Channel List, press the **RED(A)** button.
   To delete a channel from the Digital Channel List, press the **Yellow(C)** button.
   Press the **OK** button to watch that channel.
5. To renumber a channel from the DTV list, press the **Green(B)** button.
   The message "Enter new channel number." will be displayed.
6. Press the number buttons to enter a new channel number.

- Press OK button in the DVB-T view to display the Digital channel list.
- Press Blue(D) button 5 times in the DVB-T view to display the channel list.
- You can select RADIO mode by pressing the **TV/RADIO** button on the remote control.
  This button used to toggle the TV and RADIO mode.

Digital Favorite Channel

This function is possible in DVB-T mode only.
You can immediately register the present channel to the Digital Favorite Channel list.

To setup, follow steps 1~2 in page 27.

3. Press the ▲▼ buttons to select **Digital Favorite Channel**, then press **OK** or ► button.
4. To add the current channel to the Digital Favorite channels, press the **YELLOW(C)** button.
   To delete a favorite channel from the Digital Favorite channel list, press the **RED(A)** button.
   Press the **OK** button to watch that channel.

- You can also operate this function by pressing the **FAV LIST** button on the remote control.
- You can make Digital favorite channel up to 8. (TV favorite list: 4, Radio favorite list:4)
- Digital favorite channels are erased when re-scan DVT.



Setting up the System Options

This function allows you to setup the system setting.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **System**, then press the **OK** or ► button.
4. Press the ▲▼ buttons to select the desired system option, then press the **OK** or ► button.
5. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.

Downloaded From Disc-Player.com Samsung Manuals



Auto Power Off Setting

This feature automatically turns off your HDD & DVD Recorder, if you do not press any button for the selected time.

1. Press the ▲▼ buttons to select **Auto Power Off**, then press the **OK** or ► button.
2. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.
   - **Off** : Auto power off is disabled.
   - **2 Hours** : HDD & DVD Recorder will automatically turn off for 2 hours after the last button is pressed.
   - **6 Hours** : HDD & DVD Recorder will automatically turn off for 6 hours after the last button is pressed.
   - If the turn off time set with the Auto Power off function is reached during playback or recording, the device will operate until the playback or recording is finished.

▪ If you off and on the HDD & DVD Recorder, the option will be returned to default.





Automatic Chapter Creator

DVD-RW DVD-R
(V-mode)

A DVD-Video consists of 'Titles' and 'Chapters'.
When you record one programme, it makes one Title.
If you use this function, the Title will be divided into Chapters.

1. Press the ▲▼ buttons to select **Chapter Creator**, then press the **OK** or ► button.
2. Press the ▲▼ buttons to select **Off** or **On**, then press the **OK** or ► button.
   - **Off** : Select if you do not want use Automatic Chapter Creator.
   - **On** : Select this option to use the Automatic Chapter Creator feature.

   Press the **EXIT** (ⓘ) button to exit the menu.
3. Press the **REC** button to start recording.
   (See page 65 about how to set recording speed)
   The message "Do you want to create the chapter menu after this recording?" is displayed.
4. Press the ◄► buttons to select **OK**, then press the OK button.
   - A new chapter is created according to the selected recording mode. A chapter will be about 5 minutes long in XP and SP, and about 15 minutes long in LP and EP mode.
5. Press the **STOP** button to stop recording.
6. To display the created titles, finalise the disc (See page 101) and then press the **TITLE MENU** button. The title menu will be displayed.
7. To display the created chapters, select the desired Title and then press the **DISC MENU** button. The chapter menu for the selected Title will be displayed.

▪ The Automatic Chapter Creator function does not work during Timer Recording or when you turn the power off.

Downloaded From Disc-Player.com Samsung Manuals

EP Mode Time Setting



You can select one of four recording modes by pressing the REC MODE button repeatedly.
EP mode is one of four REC Mode (XP, SP, LP, EP).
In EP(Extended Play) mode, you can set recording time to 6 or 8 hours with this setting.

- 6 Hours
- 8 Hours

■ DVB-T recording is possible only on FR mode.

Anynet+ (HDMI CEC)



Anynet+ is a function that can be used to operate the recorder using a Samsung TV remote control, by connecting the HDD & DVD Recorder to a SAMSUNG TV using an HDMI Cable. (See pages 22~23) (This is only available with SAMSUNG TVs that support Anynet+.)

1. Press the ▲▼ buttons to select **Anynet+ (HDMI CEC)**, then press the **OK** or ► button.
   Anynet+ (HDMI CEC) items will be displayed.
2. Press the ▲▼ buttons to select On, then press the **OK** or ► button.

For using Anynet+ (HDMI CEC)

1. Connect the HDD & DVD Recorder to a Samsung TV with an HDMI cable. (See pages 22~23)
2. Set the Anynet+ (HDMI CEC) to "On" on your HDD & DVD Recorder. (see above)
3. Set the Anynet+ function on your TV.
   (See the TV instruction manual for more information.)

TV Menu

- You can operate the HDD & DVD Recorder by using TV remote control.
  (TV buttons that can be used to control the HDD & DVD Recorder : ⏪, ⏹, ⏯, ⏩, ▲, ▼, ◄, ►, 0~9, REC and colour buttons.)
- When you press Anynet+ button on the TV's remote control, the OSD to the left will appear.
  - **Select Device** : Use this option to select device.
  - **Record** : Use this option to start recording or stop recording.
  - **Menu on Device** : Same as **MENU** button (MENU) on the HDD & DVD Recorder remote control.
  - **Device Operation** : Same as **INFO** button (INFO) on the HDD & DVD Recorder remote control.

■ By pressing the **PLAY** button of the recorder while watching TV, the TV screen will change to the play screen.

■ If you play a DVD when the TV power is off, the TV will power On.

■ If you turn the TV off, the HDD & DVD Recorder will power off automatically. (When the HDD & DVD Recorder is recording, it can't be powered off.)

■ If you change the HDMI to other sources (Composite, Component, RF... etc) in TV while playing the DVD disc, the HDD & DVD Recorder will stop playing. But the HDD & DVD Recorder may keep the DVD disc playing certain discs based on their content.

Downloaded From Disc-Player.com Samsung Manuals

EZ Record







DVD-RW DVD-R
(V-mode)

This function allows you initialise and Finalise a disc automatically.

1. Press the ▲▼ buttons to select **EZ Record**, then press the **OK** or ► button.
2. Press the ▲▼ buttons to select **On**, then press the **OK** or ► button. Press the **EXIT** (⏻) button to exit the menu.
3. Insert a disc.
   If the disc is new, It is initialised to V mode automatically.
   (DVD-RW only)
4. Press the **REC** button.
5. EZ Record function will automatically Finalise the disc under the following conditions.
   - When you press the **OPEN/CLOSE** button on your HDD & DVD Recorder after recording on at least 70% of the disc. The tray will open after the disc has been finalised.
   - The above feature is available only when a DVD-RW(V), DVD-R disc is inserted.

- If you insert a new DVD-RW disc, It is initialised to V mode automatically.
- If you select off, you must initialise (see page 64) and finalise the disc manually in the Disc Manager menu.(see page 101)
- The length of Recording is different according to recording mode. (see page 65)

DVB-T Auto Subtitle



- **On** : The subtitle is shown automatically when receiving the DVB-T.
- **Off** : The function is cancelled.

- It is available when receiving the DVB-T that has a subtitle.

DivX(R) Registration



Please use the Registration code to register this HDD & DVD Recorder with the DivX(R) Video On Demand format. For more information, visit www.divx.com/vod

Downloaded From Disc-Player.com Samsung Manuals

Setting up the Language Options

If you set the language options, in advance, they will come up automatically every time you watch a movie.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **Language**, then press the **OK** or ► button.
   Language setup menu will be displayed.
4. Press the ▲▼ buttons to select the desired language option, press the **OK** or ► button.
   - **DVD Audio** : For the disc audio language.
   - **DVB-T Audio** : For the current broadcastig Programme provides audio.
   - **DVD Subtitle** : For the disc subtitles.
   - **DVB-T Subtitle** : For the current broadcastig Programme provides subtitles.
   - **Disc Menu** : For the disc menu contained on the disc
   - **Menu** : For the on-screen menu of your HDD & DVD Recorder.
5. Press the ▲▼ buttons to select the desired language, then press the **OK** or ► button.

- If the selected language is not recorded on the disc, the original pre-recorded language is selected.
- The selected language will only appear if it is supported on the disc and DVB-T.
- During the playback, press the **SUBTITLE** button to select DVD subtitle. Because the default of DVD subtitle is off, press the ▲▼ button to select the desired subtitle.

Setting up the Audio Options



You can connect the HDD & DVD Recorder to an external amp or Home theatre.
Allows you to setup the Audio device and sound status depending on the audio system in use.
You can also set NICAM mode.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **Audio**, then press the **OK** or ► button.
4. Press the ▲▼ buttons to select the desired audio option, then press the **OK** or ► button.
5. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.

- Press the **RETURN** or ◄ button to return to the previous menu. Press the **EXIT** ( ) button to exit the menu.

Downloaded From Disc-Player.com Samsung Manuals



Digital Output

- **PCM** : Select this when your equipment is not decode Dolby Digital (or MPEG-2) compatible.
- **Bitstream** : Outputs Dolby Digital (or MPEG-2) audio as bitstream. Select this when your AV receiver or AV amplifier has a Dolby Digital (or MPEG-2) Decoder.

- Digital output setting is equally applied to both Dolby Digital and MPEG-2 audio. LPCM sound track is always outputted as PCM. It has no relation with Digital Output setting.
- Be sure to select the correct Digital Output or you will hear no sound or a loud noise.



DTS

- **Off** : Doesn't output DTS signal. Select this when your AV receiver (or AV amplifier) does not have DTS decoder.
- **On** : Outputs DTS Bitstream via digital output when you play DTS track. Select this only when your AV receiver (or AV amplifier) have DTS decoder.

- When DTS soundtrack is played, sound does not output from AV Audio Output.



DRC

This is only active when a Dolby Digital signal is detected.

- **On** : When Movie soundtracks are played at low volume or from smaller speakers, the system can apply appropriate compression to make low-level content more intelligible and prevent dramatic passages from getting too loud.
- **Off** : You can enjoy the movie with the standard Dynamic Range.



NICAM

NICAM programmes are divided into 3 types. NICAM Stereo, NICAM Mono and Bilingual (transmission in another language). NICAM programmes are always accompanied by a standard mono sound broadcast and you can select the desired sound by setting NICAM on or off.

- **On** : NICAM mode
- **Off** : Only set at this position to record the standard mono sound during a NICAM broadcast if the stereo sound is distorted due to inferior reception conditions.

Downloaded From Disc-Player.com Samsung Manuals

V-Mode Compatibility



This feature is about the setup for selecting audios when recording the Dual STEREO (Multi-audio) broadcasting on HDD. It does not affect to the direct DVD recording of a programme.

- **Off** : Both "Dual L" and "Dual R" of the multi-audio broadcasting are recorded on HDD. Titles recorded on HDD under such setup status cannot be copied to DVD-R or DVD-RW (V mode).
- **On** : Either "Dual L" or "Dual R" of the multi-audio broadcasting is recorded on HDD. Titles recorded on HDD under such setup status can be copied to DVD-R or DVD-RW (V mode) "Dual L" and "Dual R" options can be selected from "Audio Selection."

Setting up the Video Options



This function allows you to setup the video setting.
This function depends on disc type. It may not work for some disc types.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **Video**, then press the **OK** or ► button. Video setup menu will be displayed.
4. Press the ▲▼ buttons to select the desired video option, then press the **OK** or ► button.
5. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.

■ Press the **RETURN** or ◄ button to return to the previous menu. Press the **EXIT** ( ) button to exit the menu.

TV Aspect



Depending on the type of television you have, you may want to adjust the screen setting. (aspect ratio)

- **4:3 Letter Box** : Select when you want to see the total 16:9 ratio screen DVD supplies, even though you have a TV with a 4:3 ratio screen. Black bars will appear at the top and bottom of the screen.
- **4:3 Pan-Scan** : Select this for conventional size TV when you want to see the central portion of the 16:9 screen. (Extreme left and right side of movie picture will be cut off.)
- **16:9 Wide** : You can view the full 16:9 picture on your wide screen TV.

Downloaded From Disc-Player.com Samsung Manuals



3D Noise Reduction (motion adaptive noise reduction)

- **Off** : Normal
- **On** : Provides a clear picture through noise reduction (for recording).



HDMI Resolution

This setting is used when the unit is connected by HDMI with Display devices (TV, projector, etc).

- **576P** : 720 x 576
- **720P** : 1280 x 720
- **1080i** : 1920 x 1080

Output selection

- Connect the HDD & DVD Recorder to your TV via HDMI.
  Set your TV's input to HDMI.
- Press the **P.SCAN** button while the unit is in Stop mode to select the output resolution.
  - If your TV is connected the HDMI cable, the output resolution mode changes in the following sequence each time you press the **P.SCAN** button:

    → 576P → 720P → 1080i →

  - If your TV is connected the AV or component cables(without HDMI cable), the output resolution mode toggles 576P/576i in turn.
- HDMI cable does not support 576i. Video with 576i resolution can only be viewed through the analogue outputs (Composite/S-Video/ Component).

- Even if HDMI cable is connected to your TV, the AV connection outputs only 576i and the component connection outputs only 576P irrespective of the on-screen display.
- Progressive scan automatically activates when HDMI is connected. (Please make sure PSO is indicated on the front panel of the HDD & DVD Recorder.)
- There will be no HDMI video and audio outputs unless progressive scan function is activated.
- Consult your TV instruction manual to find out if your TV supports Progressive Scan.
  If Progressive Scan is supported, follow the TV instruction manual regarding Progressive Scan settings in the TV's menu system.
- If Video Output is set incorrectly, the screen may be blocked.
- The resolutions available for HDMI output depend on the connected TV or projector. For details, see the instruction manual of your TV or projector.
- When the resolution is changed it may take a few seconds for a normal image to appear.
- If you set the HDMI output resolution 720P or 1080i, HDMI output provides better picture quality.

Downloaded From Disc-Player.com Samsung Manuals

Progressive scan

If your TV supports Progressive Scan, press the P.SCAN button on the front of the HDD & DVD Recorder.
To view 'Progressive scan mode', first connect the component cable. (See page 20)
Be sure the Component cables are connected properly.



◆ Setting up the Progressive scan

1. With the unit in Stop mode, press the **P.SCAN** button on the front of the HDD & DVD Recorder.
   The message "Press [Yes] to confirm Progressive scan mode. Otherwise, press [No]." will appear.
2. Press the ◄► buttons to select **Yes**, and then press the **OK** button.
3. Set your TV to Progressive input (using the TV remote control.)

- When the HDMI cable (not supplied) is connected, this screen is not displayed.
- If the **P.SCAN** button on the HDD & DVD Recorder's front panel is pressed during playback, the message "This function is possible only on stop mode" appears on the screen.
- Progressive setting is only available when the HDD & DVD Recorder is in stop mode.



◆ Cancelling the Progressive scan

1. With the unit in Stop mode, press the **P.SCAN** button on the front of the HDD & DVD Recorder.
   The message "Press [Yes] to confirm Interlace scan mode. Otherwise, press [No]." will appear.
2. Press the ◄► buttons to select **Yes**, and then press the **OK** button.
3. Set your TV to Interlace input (using the TV remote control.)

- Do not press the **P.SCAN** button if you are using a TV that does not support Progressive mode as nothing will be displayed on the screen.
- If you press the **P.SCAN** button by mistake when your TV does not support Progressive mode, the mode will then need to be released. To release the Progressive mode, press the **P.SCAN** button on the front panel 3 times. The screen will recover after the **PSO** indicator on the front panel display turns off.

Downloaded From Disc-Player.com Samsung Manuals

Setting up the Parental Lock



DVD-VIDEO

The Parental Lock function works in conjunction with DVDs and DVB-T that have been assigned a rating which helps you control the types of DVDs that your family watches. There are up to 8 rating levels on a disc.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Setup**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **Parental Lock**, then press the **OK** or ► button.
   When you operate your HDD & DVD Recorder for the first time, the "Create the Password" message will be displayed.
4. Enter the 4-digit password using the number buttons on the remote control.
   The "Confirm the password" message will be displayed. Enter your password again.

▪ Press the **RETURN** or ◄ button to return to the previous menu.
Press the **EXIT** (⏻) button to exit the menu.

If you forgot your password

1. Remove the disc.
2. Press and hold the **PROG** (∨ ∧) button on the front panel for 5 seconds or more.

Setting the Programme Grade



1. Press the ▲▼ buttons to select **Programme Grade**, then press the **OK** or ► button.
2. Press the ▲▼ buttons to select the programme grade you want, then press the **OK** or ► button.
   For example, if you select up to G, DVB-T that contain C, P will not display. A larger number indicates that the programme is intended for adult use only.

◆ **Parental information for Australia**

P (Pre-school)	This program is designed to be appropriate for pre-school children.
C (Children's)	This program is designed to be appropriate for all children.
G (General Audience)	This program is designed to be appropriate for all ages.
PG (Parental Guidance Recommended)	This program contains unsuitable materials that parents want to prevent their children from watching.
M (Mature Audience 15+)	Programs are blocked for children under the age of 15.

Downloaded From Disc-Player.com Samsung Manuals

MA (Mature Adult Audience 15+)	Programs are blocked for children under the age of 15.
AV (Adult Audience strong violence 15+)	This program contains the strong violent contents. Therefore, programs are blocked for children under the age of 15.
R (Restricted 18+)	Programs are blocked for children under the age of 18.

Setting the DVD Level



1. Press the ▲▼ buttons to select **DVD Level**, then press the **OK** or ► button.
2. Press the ▲▼ buttons to select the **DVD Level** you want, then press the **OK** or ► button.
   For example, if you select up to 6, discs that contain 7, 8 will not play. A larger number indicates that the programme is intended for adult use only.

Changing the Password

1. Press the ▲▼ buttons to select **Change Password**, then press the **OK** or ► button.
2. Enter the 4-digit password using the number buttons on the remote control. The "Confirm the password" message will be displayed.
3. Enter your password again using the number buttons on the remote control.

Downloaded From Disc-Player.com Samsung Manuals

'EPG' is used as the same meaning with 'TNT'.

Basic Functions

Display Screen

After the television channels have been stored, you will see the following picture(banner) each time you switch channels.
You can use this function when you see DVB-T.

1. Press the *i* button once to display the channel and the channel name.

2. Select the channel by pressing the **NUMBER** buttons or **PROG** (∧ / ∨) buttons to move to **TV** channel.
You will also see this banner each time you change channels.



◆ Banner Elements

1. Displays the programme grade.
2. Displays the favorite channel.
3. Displays the paid channel.
4. Displays the subtitle.
5. Displays the number of audio.
6. Displays the teletext.

- Detailed programme information -

1. Press the *i* button twice while you are viewing a programme.
2. After the *i* button is pressed for the second time, detailed information for current programme can be displayed on another banner, if there is more information.

Select Audiotrack

1. Press the **ALT** button to see the Audio track list.

2. Press the ▲▼ buttons to select desired Audio track, then press the **OK** button.

Downloaded From Disc-Player.com Samsung Manuals

Setting the Favorite Channel

You can immediately register the present channel to the Digital Favorite Channel List.

1. Press the **FAV LIST** button while you are viewing a programme.

2. To add the current channel to the Digital Favorite channels, press the **YELLOW(C)** button.
To delete a favorite channel from the Digital Favorite channel list, press the **RED(A)** button.

– To watch the favorite channel –

Press the **FAV LIST** button and then select the channel.
Press the **OK** button to watch that channel.

- You can make up to 8 Digital favorite channel. (TV favorite list: 4, Radio favorite list:4)
- Digital favorite channels are erased when re-scan DVT.

Changing the Subtitle Language

When the current broadcasting programme provides subtitle, press the SUBTITLE button . If Subtitle is available on current programme, menu bar is displayed on the upper side.

1. Press the **SUBTITLE** button.

2. Press the ▲▼ buttons to select a desired subtitle, then press the **OK** button.

- "(Teletext)" postfixed subtitles cannot be recorded.

Setting the Teletext OSD

When the current broadcasting programme provides teletext, press the TEXT button to see the teletext. If teletext is available on current programme, menu bar is displayed on the upper side.

1. Press the **TEXT** button.

2. Press the ▲▼ buttons to select a desired teletext.

3. Press the ◄► button to select transparency, then press the **OK** button.

Downloaded From Disc-Player.com Samsung Manuals

Guide



The electronic programme guide gives you a channel list for the channels.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Guide**, then press the **OK** or ► button.
   - Press the **GUIDE** button while you are viewing a programme. (DTV)
   - **RED(A) button (Timer Record)** : Setting the Timer Record.
   - **(►►I)button** : Go to next day
   - **(I◄◄)button** : Go to previous day
     → It displays programme from now to 8 days after.
   - **▲▼◄► button** : select the programme and station.
   - **INFO button (Information)** : View the detail information

- The contents of cell could be displayed with a delay according to the broadcasting.
- On entering Guide screen, currently selected channel's information will be displayed on the right side of PIP (Picture in Picture).
- The following icon is displayed if EPG data includes genre information:

Movie	News	Entertainment	Sport	Children's	Music	Arts/ Culture
Current Affairs	Education/ Information	Infotainment	Special	Comedy	Drama	Documentary

Guide Timer Recording





Make sure that clock must be set before operating this function. (see pages 26~27)

1. Press the ▲▼◄► buttons to select desired programme, then press **RED(A)** or **OK** button.
2. The time of Guide is the time of the current channel enters.
3. You can check the setting in the scheduled List. (see pages 73~74)

- The title information is displayed in the Title List as for Guide REC.
- If Timer Rec is set, the icon is displayed in the set programme.
- Up to 12 recording are possible including guide recording and general recording.

Downloaded From Disc-Player.com Samsung Manuals

Playback

This section introduces basic functions of playback and playback by disc type.
Read the following information before playing a disc.

Region code (DVD-Video only)

Both the HDD & DVD Recorder and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play. The Region Number for this HDD & DVD Recorder is described on the rear panel of the HDD & DVD Recorder.

Logos of Discs that can be played

Dolby Digital

DTS

Digital Audio

Stereo

PAL broadcast system in U.K, France, Germany, etc.

DivX

MP3

Disc types that can be played

Disc Types		Disc Logo content	Recorded content	Disc Shape	Max. Playing Time
DVD-VIDEO		DVD VIDEO	AUDIO VIDEO	Single sided(12cm)	240 min.
				Double sided(12cm)	480 min.
				Single sided(8cm)	80 min.
				Double sided(8cm)	160 min.
AUDIO-CD		COMPACT disc DIGITAL AUDIO	AUDIO	Single sided(12cm)	74 min.
				Single sided(8cm)	20 min.
JPEG			JPEG Image	Single sided(12cm)	–
				Single sided(8cm)	–
MP3			MP3 Audio	Single sided(12cm)	–
				Single sided(8cm)	–
DivX		DivX	DivX Movie	Single sided(12cm)	–
				Single sided(8cm)	–
DVD-RAM		DVD RAM	AUDIO VIDEO	Single sided(12cm) (4.7GB)	1 hr. (XP : Excellent Quality)
					2 hrs. (SP : Standard Quality)
					4 hrs. (LP : Long Playback)
					6 or 8 hrs. (EP : Extended)
				Double sided(12cm) (9.4GB)	2 hrs. (XP : Excellent Quality)
					4 hrs. (SP : Standard Quality)
					8 hrs. (LP : Long Playback)
					12 or 16 hrs. (EP : Extended)
DVD-RW		DVD RW	AUDIO VIDEO	12cm (4.7GB)	1 hr. (XP : Excellent Quality)
					2 hrs. (SP : Standard Quality)
					4 hrs. (LP : Long Playback)
					6 or 8 hrs. (EP : Extended)
DVD-R		DVD R	AUDIO VIDEO	Single Layer(12cm) (4.7GB)	1 hr. (XP : Excellent Quality)
					2 hrs. (SP : Standard Quality)
					4 hrs. (LP : Long Playback)
					6 or 8 hrs. (EP : Extended)
				Dual Layer(12cm) (8.5GB)	1 hr. 50min (XP : Excellent Quality)
					3 hrs. 40min (SP : Standard Quality)
					7 hrs. 20min (LP : Long Playback)
					11 or 14 hrs. 40min (EP : Extended)
DVD+RW		RW DVD+ReWritable	AUDIO VIDEO	12cm (4.7GB)	–
DVD+R		RW DVD+R / RW DVD+R DL	AUDIO VIDEO	Single Layer(12cm) (4.7GB)	–
				Dual Layer(12cm) (8.5GB)	–
CD-R/-RWDVD-RAM/-RW/-R			JPEG MP3 DivX	–	–
HDD	DVD-SH853 (160GB)	HDD	AUDIO VIDEO		Approx. 41 (XP : Excellent Quality) Approx. 67 (SP : Standard Quality) Approx. 133 (LP : Long Playback) Approx. 199 or Approx. 264 (EP : Extended)
	DVD-SH855 (250GB)				Approx. 64 (XP : Excellent Quality) Approx. 106 (SP : Standard Quality) Approx. 211 (LP : Long Playback) Approx. 316 or Approx. 421 (EP : Extended)

Downloaded From Disc-Player.com Samsung Manuals

Discs that cannot be played

- DVD-Video with a region number other than "4" or "ALL"
- 3.9 GB DVD-R Disc for Authoring.
- DVD-RAM/-RW(VR mode) not recorded following the Video Recording Standard
- A DVD±R/DVD-RW(V) disc which has been recorded and not finalised in a different manufacturer's recorder.
- DVD-ROM/PD/MV-Disc, etc
- VCD/SVCD/CVD/CD-ROM/CDV/CD-G/CD-I
- BD, HD-DVD

- This HDD & DVD Recorder can only operate with discs that are compatible with DVD-RAM Standard Version 2.0.
- Playback and/or recording may not work for some types of discs, or when specific operations, such as angle change and aspect ratio adjustment, are being performed. Information about the discs is written in detail on the box. Please refer to this if necessary.
- Do not allow the disc to become dirty or scratched, finger prints, dirt, dust, scratches or deposits of cigarette smoke on the recording surface may make it impossible to use the disc for recording.
- DVD-RAM/±RW/±R discs may not be able to play on some DVD players, depending on the player, disc and the condition of the recording.
- Discs with NTSC programmes recorded on them can be played but cannot be recorded using this product.

Playing a Disc

1. Press the **OPEN/CLOSE** button.
2. Place a disc gently into the tray with the disc's label facing up.
3. Press the **OPEN/CLOSE** button to close the disc tray.
   - The HDD & DVD Recorder does not play discs automatically after being powered on initially.
   - When the HDD & DVD Recorder is powered on and a disc is in the tray, the unit will be activated and wait in stop status.
   - Press the **PLAY**(⏯) button to start playback.
4. Press the **STOP**(■) button to stop playback.

- When you stop playing back a disc, the HDD & DVD Recorder remembers where you stopped, so when you press **PLAY**(⏯) button again, it will pick up where you left off. (Unless the disc is removed or the HDD & DVD Recorder is unplugged, or if you press the **STOP**(■) button twice.)

Downloaded From Disc-Player.com Samsung Manuals

- Do not move your HDD & DVD Recorder while playing, as this may cause damage to the disc.
- Make sure to press the **OPEN/CLOSE** button to open or close the disc tray.
- Do not push the disc tray while it is being opened or closed, as this may cause a product malfunction.
- Do not place foreign materials on or in the disc tray.
- Some functions may perform differently or be disabled depending on the disc type.
  If this occurs, refer to the instructions written on the disc case.
- Be especially careful that children's fingers are not caught between the disc tray and the tray chassis when it closes.
- You must only insert one DVD disc at a time. Inserting two or more discs will not allow playback and may cause damage to the HDD & DVD Recorder.

Using the Disc Menu & Title Menu

Some type of discs contain a dedicated menu system that allows you to select special functions for title, chapter, audio track, subtitle, film preview, information on characters, etc.

For DVD-VIDEO Disc

- **Disc Menu** : Press the **DISC MENU** button to enter the disc menu of the disc.
  - Move to the setup menu related to playback operation.
  - You can select audio language and subtitle etc. provided by the disc.
- **Title Menu** : Press the **TITLE MENU** button to move to the title menu of the disc.
  - Some discs may not support the title menu functionality.

For HDD/DVD-RAM/±RW/±R Disc

- **Title List**
  Press the **TITLE LIST** button. Title List is a list of previously recorded programmes. If a title is deleted, that title cannot be played again.
- **Play List (HDD/DVD-RAM/-RW(VR))**
  Press the **PLAYLIST** button. This refers to a list of user-selected titles. When one playlist is played, only the scene selected by the user will play and then stop. Since only the information necessary for playing a desired scene is included in a playlist, even if that playlist is deleted, the original recording will not be deleted. (only VR mode)

Downloaded From Disc-Player.com Samsung Manuals

Using the playback related buttons

Searching through a Chapter or Track

HDD DVD-VIDEO DVD-RAM DVD-RW DVD-R CD DVD+RW DVD+R

During play, press the **SEARCH** (◀◀ ▶▶) buttons on the remote control.

HDD/DVD-VIDEO/ DVD-RAM/±RW/±R	▶▶ X 2 → ▶▶ X 4 → ▶▶ X 8 → ▶▶ X 16 → ▶▶ X 32 → ▶▶ X 128
DivX	▶▶ X 2 → ▶▶ X 4 → ▶▶ X 8
AUDIO CD (CD-DA)	▶▶ X 2 → ▶▶ X 4 → ▶▶ X 8

- You can scan the programme in reverse.
- When you press and hold the **SEARCH** (◀◀ ▶▶) buttons, playback is done at the default speed of X 4.
  If you release the **SEARCH** (◀◀ ▶▶) buttons , playback is performed at a normal speed.
- To return to normal speed playback, press the **PLAY** (▶❚) button.

- No sound is heard during Scan(Search) mode, except with CDs (CD-DA).
  (You can hear sound during forward search(X 2) in disc.)
- The speed marked in this function may be different from the actual playback speed.

Skipping Chapters, Titles or Markers

HDD DVD-RAM DVD-RW DVD-R CD DVD+RW DVD+R

During play, press the **SKIP** (⏮ ⏭) buttons on the remote control.

- **If you press the SKIP (⏮) button,**
  it moves to the beginning of the chapter or Title or marker
  Pressing the button once again within 3 seconds returns to the beginning of the previous chapter or Title or marker
- **If you press the SKIP (⏭) button,**
  it moves to the next chapter or track or marker

Downloaded From Disc-Player.com Samsung Manuals

Slow Motion Play

HDD DVD-VIDEO DVD-RAM DVD-RW DVD-R DVD+RW DVD+R DivX

In pause mode, press the **SEARCH** (◀◀ ▶▶) buttons on the remote control.

- **If you press the SEARCH (▶▶) button,**
  ▮▶ 1/2 ➞ ▮▶ 1/4 ➞ ▮▶ 1/8
- **If you press the SEARCH (◀◀) button,**
  ◀▮ 1/2 ➞ ◀▮ 1/4 ➞ ◀▮ 1/8
- To return to normal speed playback, press the **PLAY** (▶▮) button.

Press and hold the **SEARCH** (◀◀ ▶▶) buttons during pause, the disc will play slowly at 1/4 speed. If the button is released, the pause operation will resume.

- The speed marked in this function may be different from the actual playback speed.
- Slow motion operates only in the forward direction on DivX discs.

Step Motion Play

HDD DVD-VIDEO DVD-RAM DVD-RW DVD-R DVD+RW DVD+R DivX

Press the **SKIP**(⏮, ⏭) buttons on the remote control in the pause mode.

- Each time the button is pressed, a new frame will appear.
  When the **SKIP**(⏮) button is pressed, the previous frame will be activated.
  When the **SKIP**(⏭) button is pressed, the next frame will be activated.
- To return to normal speed playback, press the **PLAY** (▶▮) button.

- Step motion operates only in the forward direction on DivX discs.

Downloaded From Disc-Player.com Samsung Manuals

Using the INFO button

The INFO function allows you to easily search for a desired scene by accessing title, chapter, time.
You can also change the subtitle and audio settings and set some features including Angle, Repeat, Zoom.

Moving to a scene directly using the INFO

HDD DVD-VIDEO DVD-RAM DVD-RW DVD-R DVD+RW DVD+R DivX



If you want to move to a certain title, chapter or time, use this function.

1. Press the **INFO** button during playback.
2. Press the ▲▼ buttons to select **Search**, then press the **OK** button or ► button.
3. Press the ▲▼ buttons to select **Title, Chapter** or **Time**.
4. Press the ◄► buttons or number buttons to select the desired scene, then press the **OK** button.
   In case of searching a time, enter the time in the sequence of hours, minutes, and seconds using the number buttons.
   Then press the **OK** button.

- This may not work for some discs.
  When an audio CD(CD-DA) or an MP3/JPEG disc is inserted, depending on the disc type, the information display may not appear.
- The Time Search function does not operate in some discs.
- To make the screen disappear, press the **RETURN** button.

Selecting the Subtitle Language

DVD-VIDEO DivX



Selects one of the subtitle language recorded on the disc.
You can also operate this function by pressing the SUBTITLE button on the remote control.

1. Press the **INFO** button during playback.
2. Press the ▲▼ buttons to select **Subtitle**.
3. Press the ◄► buttons to select the desired subtitle language.

- The subtitle display may be different depending on the disc type.
- Some discs allow you to select the language for the disc menu only.

Downloaded From Disc-Player.com Samsung Manuals

Selecting the Soundtracks & Audio Channels

HDD DVD-VIDEO DVD-RAM DVD-RW DVD+RW DVD+R DivX



Selects one of the soundtracks recorded on the disc. Also selects the audio channels from recorded TV programmes.
You can also operate this function by pressing the AUDIO button on the remote control.

1. Press the **INFO** button during playback.
2. Press the ▲▼ buttons to select **Audio**.
3. Press the ◄► buttons to select the desired sound tracks or audio channel.

- Soundtracks or Audio channel may be different because they are disc-specific.
- Some discs allow you to select the audio language for the disc menu only.

Changing the Camera Angle

DVD-VIDEO



When a DVD VIDEO contains multiple angles of a particular scene, you can select the Angle function.

1. Press the **INFO** button during playback.
2. Press the ▲▼ buttons to select **Angle**.
3. Press the ◄► buttons to select the desired angle.

- This function is disc-dependent, and may not work on all DVDs.
- This function does not work when a DVD has not been recorded with a multi-camera angle system.
- Displays the current angle, total angle number.

Downloaded From Disc-Player.com Samsung Manuals

Playing Repeatedly (Repeat Playback)

HDD DVD-VIDEO DVD-RAM DVD-RW DVD-R DVD+RW DVD+R DivX



You can also operate this function by pressing the REPEAT button on the remote control.

1. Press the **INFO** button during playback.
2. Press the ▲▼ buttons to select the **Repeat**.
3. Press the ◄► buttons to select **Off, A-B** or **Title** or **Chapter** you want to play repeatedly, then press the **OK** button.

- HDD/DVD-RAM/-RW(VR mode), unfinalised DVD±R and unfinalised DVD-RW (V mode) discs will not repeat a chapter.
- You can also activate Normal Playback by pressing the **EXIT**() button.

Repeat A-B

HDD DVD-VIDEO DVD-RAM DVD-RW DVD-R DVD+RW DVD+R





1. Press the **INFO** button during playback.
2. Press the ▲▼ buttons to select **Repeat**.
3. Press the ◄► buttons to select **Repeat A-B**, then press the **OK** button.
4. Press the **OK** button at the point where you want the repeat play to start (A) and press it again at the point where you want the repeat play to stop (B). Repeat playback of the A-B section starts.

- If you set point (B) before five seconds of playback has lapsed, the prohibition mark (⊘) will appear.
- You can also activate Normal Playback by pressing the **EXIT**() button.
- Audio CDs(CD-DA), MP3 discs and DivX discs do not support the Repeat A-B function.

Downloaded From Disc-Player.com Samsung Manuals

Zooming-In

HDD DVD-VIDEO DVD-RAM DVD-RW DVD-R DVD+RW DVD+R



1. Press the **INFO** button during playback.
2. Press the ▲▼ buttons to select **Zoom**, then press the **OK** or ► button. (🔍) will be displayed.
3. Press ▲▼◄► buttons to move to the area you want to enlarge.
4. Press the **OK** button.
   The screen will be enlarged to twice the normal size. The screen size will be enlarged to four times the normal size.

HDD/DVD-VIDEO/ DVD-RAM/±RW/±R	normal size → X2 → X4 → X2 → normal size

- When the recording is done in EP mode, the zoom function is not supported except when the recording has been in DVD-VIDEO and finalised DVD-R/-RW(V).

Downloaded From Disc-Player.com Samsung Manuals



Using Markers

HDD DVD-RAM DVD-RW

(VR mode)

Set marks at scenes you want to see again so that you can start playback from the marked position.

Setting Markers

1. Press the **MARKER** button during playback.
2. Press the **OK** button when the desired scene appears.
   - The number 01 is displayed and the scene is memorised.
3. Press the ► buttons to move to the next position.
4. Press the **OK** button again when the desired scene appears.
   - The number 02 is displayed and the scene is memorised.
   - HDD, DVD-RAM or DVD-RW (VR Mode) discs have the Marker function instead of the Bookmark function. Since the scenes may be displayed as many different pages, numbering is necessary. If a disc in use is encoded with Disc Protection, Markers cannot be set or deleted, only playback is available.

Playing back a marker

1. Press the **MARKER** button during playback.

2. Press the ◄► buttons to select a marked scene.

3. Press the **OK** or **PLAY** (⏯) button to start playing from the selected scene.
   - If you press the **SKIP** (⏮) button, it moves to the beginning of the marker. Pressing the button once again within 3 seconds returns to the beginning of the previous marker.
   - If you press the **SKIP** (⏭) button, it moves to the next marker.

Clearing a marker

1. Press the **MARKER** button during playback.

2. Press the ◄► buttons to select a marked scene.

3. Press the **RED(A)** button to delete the selected mark.
   - When a marker is cleared while HDD/DVD-RAM/-RW (VR mode) is playing, marker numbers will change. For example, if the 7th marker is cleared after ten markers are registered, the marker numbers after the eighth will automatically move ahead by one and the 8th marker becomes the 7th.

Downloaded From Disc-Player.com Samsung Manuals

Using the Bookmarks



DVD-VIDEO DVD-RW DVD-R DVD+RW DVD+R

(V mode)

Setting Bookmarks

1. Press the **MARKER** button during playback.
2. Press the **OK** button when the desired scene appears.
   - The number **1** is displayed and the scene is memorised.
3. Press the ► buttons to move to the next position.
4. Press the **OK** button again when the desired scene appears.
   The number **2** is displayed and the scene is memorised.
   - Repeat above to bookmark other positions.
   - You can bookmark up to 10 scenes.

■ When the disc tray is opened and then closed, bookmarks will disappear.

Playing back a bookmark

1. Press the **MARKER** button during playback.
2. Press the ◄► buttons to select a bookmarked scene.
3. Press the **OK** or **PLAY**(⏯) button to start playing from the selected scene.

Clearing a bookmark

1. Press the **MARKER** button during playback.
2. Press the ◄► buttons to select a bookmarked scene.
3. Press the **RED(A)** button to delete the selected bookmark.

Downloaded From Disc-Player.com Samsung Manuals



Playing an Audio CD/MP3

Buttons on the Remote Control used for Audio CD(CD-DA)/MP3 playback

1. ▲▼ : Selects a track (song).
2. **OK button, Play (⏯) button**: Plays the selected track (song).
3. **SKIP (⏭) button** : Moves to the next page.
4. **SKIP (⏮) button** : Moves to the previous page.
5. **Press the SEARCH (⏪ ⏩) buttons** : Fast Play (X 2, X 4, X 8) (Audio CD only)
6. **STOP (⏹) button** : Stops a track(song).
7. **PLAY (⏯) button** : Plays a track(song) or pauses playback.
8. **RED(A) button** : ● Creates a playlist or go to playlist.
   ● Select Copy and Select All button.(MP3 disc only)
9. **GREEN(B) button** : Selects the sort order. (MP3 disc only)
10. **YELLOW(C) button** : Selects the play mode. (REPEAT)
11. **BLUE(D) button** : Selects a contents. (MP3 disc only)

Playing an Audio CD(CD-DA)

1. Insert an audio CD (CD-DA) into the disc tray.
   • The audio CD menu appears and the tracks (songs) are played automatically.
2. Press the ▲▼ buttons to select the track (song) you want to hear, and then press the **OK** button.



◆ Audio CD(CD-DA) Screen Elements

1. **Current track (song)** : Displays the number of the track currently being played.
2. Displays available buttons and a playback time corresponding to a portion that is currently played.
3. Displays the current file type and file name.
4. Display available buttons.
5. Displays the current play index, total track number.
6. Displays the track list (song list).

Downloaded From Disc-Player.com Samsung Manuals

Playing an MP3 Disc

1. Insert an MP3 disc into the disc tray.
   - The menu is displayed
2. Press the ▲▼ buttons to select **Library**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **Music**, then press the **OK** or ► button.
4. Press the ▲▼ buttons to select the track you want to hear, and then press the **OK** button.



◆ MP3 Screen Elements

1. **Current track (song)** : Displays the name of the track being played.
2. Displays available buttons and a playback time corresponding to a portion that is currently played.
3. Displays the current file type, file name and folder name.
4. Displays available buttons.
5. Displays the current play index, total track number.
6. Displays the track list (song list).

Repeat CD (CD-DA) & MP3



You can also operate this function by pressing the REPEAT button on the remote control. During playback, press the REPEAT button repeatedly to select the repeat mode you want.

1. Press the **YELLOW(C)** button during the Music List playback.
2. Press the ▲▼ buttons to select desired play mode, then press the **OK** or ► button.
   - **Normal (CD (CD-DA)/MP3)** : Tracks on a disc are played in the order in which they were recorded on the disc.
   - **Repeat Track (CD (CD-DA)/MP3)**
   - **Repeat Folder (MP3)**
   - **Repeat All (CD (CD-DA)/MP3)**
   - **Random (CD (CD-DA)/MP3)** : The random option plays a disc's tracks in random order.

Downloaded From Disc-Player.com Samsung Manuals

New Playlist





You can register a maximum 30 tracks in the playlist.

1. Press the **RED(A)** button during the Music List playback.
2. Press the ▲▼ buttons to select **New Playlist**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select tracks in the order in which you want them to play, then press the **OK** button.
   - If you playlisted a wrong track, press the ►▲▼ buttons to select the wrong track, then press the **OK** button.
4. To store the Playlist, press the **RED(A)** button.
   A new Playlist will be created.

Go To Playlist



1. Press the **RED(A)** button during the Music List playback.
2. Press the ▲▼ buttons to select **Go To Playlist**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select the desired playlist folder, then press the **OK** button.
   The selected tracks are played automatically.

Downloaded From Disc-Player.com Samsung Manuals



Delete the Playlist

1. Press the **RED(A)** button during the Music List playback.
2. Press the ▲▼ buttons to select **Go To Playlist**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select the Playlist you want to delete.
4. Press the **RED(A)** button.
5. Press the ◄► buttons to select **Yes**, then press the **OK** button.
   The selected Playlist is deleted.





Go To Edit Playlist

1. Press the **RED(A)** button during the Music List playback.
2. Press the ▲▼ buttons to select **Go To Playlist**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select the Playlist you want to edit.
4. Press the **GREEN(B)** button in playlist mode.
5. Press the ▲▼ buttons to select tracks in the order in which you want them to play, then press the **OK** button.
   - If you playlisted a wrong track, press the ►▲▼ buttons to select the wrong track, then press the **OK** button.
6. To store the Playlist, press the **RED(A)** button.
   Playlist will be edited.



Go To Music List

1. Press the **BLUE(D)** button during the Playlist playback.
   The Music List will be displayed.

Downloaded From Disc-Player.com Samsung Manuals

Using the Sort

When you need to change the Sort order of Music List, you can change it simply.

1. While the list menu is displayed, press the **GREEN(B)** button to select Sort.
2. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.
   - **Name** : In alphabetical order
   - **Size** : In order of audio file size.

- Audio CD(CD-DA) is not available.
- You can sort by Name, Length. Sorted list will be resorted in copied order upon reentering Music List.

Select Contents

1. Press the **BLUE(D)** button to select **Contents**.
2. Press the ▲▼ buttons to select the contents you want to move, then Press the **OK** or ► button.

- This function is possible only when the disc contains the selected contents.
- Audio CD(CD-DA) is not available.

Downloaded From Disc-Player.com Samsung Manuals

Viewing a Picture



JPEG

1. Insert a JPEG disc into the disc tray.
   - The menu is displayed
2. Press the ▲▼ buttons to select **Library**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **Photo**, then press the **OK** or ► button.
   - To see the next 8 pictures, press the **SKIP** (⏭) button.
   - To see the previous 8 pictures, press the **SKIP** (⏮) button.
4. Press the ▲▼◄► buttons to select a desired picture, then press the **OK** button.

Slide Show





5. Press the **PLAY** (⏯)button.
   - Once in the Photo List, you can also operate slideshow in by pressing the **YELLOW(C)** button.
6. Press the **RED(A)** button to select Speed.
7. Press the ▲▼ buttons to select the slideshow speed, then press the **OK** or ► button.
   The slideshow starts and plays at the selected speed.
   - You can go to **Photo List** by pressing **YELLOW(C)** button.

◆ To stop the Slide Show

Press the **GREEN(B), STOP**(■) or **RETURN** button.

Rotate





To setup, follow steps 1 to 4 .

5-1. Press the **GREEN(B)** button to select Rotate.

6. Press the ▲▼ buttons to select the rotate angle, then press the **OK** or ► button.
   - Once you select a rotate angle, you can change it by pressing the **RED(A)** button.
   - You can go to **Photo List** by pressing **YELLOW(C)** button.

◆ To stop the Rotate

Press the **GREEN(B), STOP**(■) or **RETURN** button.

Downloaded From Disc-Player.com Samsung Manuals



Zoom

To setup, follow steps 1 to 4 in page 59.

5-1. Press the **YELLOW(C)** button to select Zoom.

6. Each time the **OK** button is pressed, the picture is enlarged up to 4x (four times the normal size).

X2 → X4 → X2 → Normal

- You can go to **Photo List** by pressing **YELLOW(C)** button.

◆ To stop the Zoom

Press the **GREEN(B)**, **STOP**(■) or **RETURN** button.

Go To Photo List

To setup, follow steps 1 to 4 in page 59.

5-1. Press the **RETURN** button to go to **Photo List**.

Using the Sort



When you need to change the Sort order of Photo List, you can change it simply.

1. While the list menu is displayed, press the **GREEN(B)** button to select **Sort**.
2. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.
   - **Name** : In alphabetical order
   - **Size** : In order of photo file size.

■ You can sort by Name, Size. Sorted list will be resorted in copied order upon reentering Photo List.

Select Contents



To setup, follow steps 1 to 3 in page 59.

1. Press the **BLUE(D)** button to select **Contents**.
2. Press the ▲▼ buttons to select the contents you want to move, then Press the **OK** or ► button.

■ This function is possible only when the disc contains the selected contents.

Downloaded From Disc-Player.com Samsung Manuals

Playing a DivX

Using the MENU button



1. Insert a DivX disc into the disc tray.
   • The menu is displayed
2. Press the ▲▼ buttons to select **Library**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **DivX**, then press the **OK** or ► button.
4. Press the ▲▼ buttons to select the avi file (DivX), then press the **OK** or **PLAY** (⏯) button.
5. When DivX file is played, you can use following functions. Pressing the **STOP** (⏹) button once during playback will display the file list, pressing the button again will exit the menu screen.

DivX Function Description

Function	Description
Skip	During play, press the **SKIP** (⏮⏭) buttons, it moves forward or backward 5 minutes.
Search	During play, press the **SEARCH** (⏪⏩) buttons and press again to search at a faster speed. (X 2, X 4, X 8)
Slow Motion Play	In pause mode(II Pause), press the **SEARCH** (⏩) button on the remote control. (1/2, 1/4, 1/8) Reverse Slow Motion Play is not available.
Step Motion Play	In pause mode(II Pause), press the **SKIP** (⏭) buttons on the remote control. Reverse Step Motion Play is not available.

- This unit can play the following video compression formats,
  - DivX Video (Codec) Format : DivX 3.11 DivX 4.x DivX 5.x (without QPEL and GMC)
  - DivX Audio (Codec) Format : MP3, MPEG1 Audio Layer 2, LPCM, AC3
- Supported subtitle file formats: .smi, .srt, .sub, .psb, .txt, .ass (The subtitle file should have exactly the same name to corresponding DivX file name)
- Some DivX files created on a personal computer may not be play back. That is why Codec Type, Version and Higher resolution over specification are not supported.
- You cannot play back the disc that is larger than a 720 x 576 pixel resolution.

Downloaded From Disc-Player.com Samsung Manuals

DivX Subtitle Encoding



1. Press the **YELLOW(C)** button in the file list.
2. Press the ▲▼ buttons to select a supported DivX subtitle language by region, then press the **OK** button.

Western	Afrikaans, Basque, Catalan, Danish, Dutch, English, Faeroese, Finnish, French, German, Icelandic, Indonesian, Italian, Malay, Norwegian, Portuguese, Spanish, Swahili, Swedish
Central	English, Albanian, Croatian, Czech, Hungarian, Polish, Romanian, Serbian(Latin), Slovak, Slovenian
Greek	English, Greek
Cyrillic	English, Azeri, Belarusian, Bulgarian, Kazakh, Macedonian, Russian, Serbian, Tatar, Ukrainian, Uzbek

- If the subtitle language is displayed in broken fonts, change DivX Subtitle to the appropriate region. If is still does not work, the format is not supported.

Using the Sort



When you need to change the Sort order of DivX List, you can change it simply.

1. While the list menu is displayed, press the **GREEN(B)** button to select **Sort**.
2. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.
   - **Name** : In alphabetical order
   - **Size** : In order of DivX file size.

- You can sort by Name, Size. Sorted list will be resorted in copied order upon reentering DivX List.

Select Contents



1. Press the **BLUE(D)** button to select **Contents**.
2. Press the ▲▼ buttons to select the contents you want to move, then Press the **OK** or ► button.

- This function is possible only when the disc contains the selected contents.

Downloaded From Disc-Player.com Samsung Manuals

Recording

This section shows various HDD&DVD Recording methods.
This unit can record on various types of discs. Before recording, read the following instructions and select the disc type according to your preference.

Recordable Discs

This HDD & DVD Recorder can record on the following discs.

HDD	DVD-RAM	DVD-RW	DVD-R
HDD	DVD RAM	DVD RW	DVD R

•DVD-RAMs and DVD-RWs are rewritable.
•DVD-Rs are non-rewritable.

Compatibility between Samsung and Other Company's Recorder

Disc Types	Recording format	Recording Device	Finalising	Additional Recording in Samsung Recorder
DVD-RAM	VR Mode	Samsung	X	Recordable
		Other Company	X	Recordable
DVD-RW	VR Mode	Samsung	finalised	Not recordable
			not finalised	Recordable
		Other Company	finalised	Not recordable
			not finalised	Recordable
	V Mode	Samsung	finalised	Not recordable
			not finalised	Recordable
		Other Company	finalised	Not recordable
			not finalised	Not recordable
DVD-R	V Mode	Samsung	finalised	Not recordable
			not finalised	Recordable
		Other Company	finalised	Not recordable
			not finalised	Not recordable

- Finalise
  - This closes the DVD-RW/-R so no additional recording can be done.
- Unfinalise
  - This allows additional recording on a DVD-RW disc originally recorded on the HDD & DVD Recorder.
  - A DVD-RW disc that has been recorded by DAO(Disc At Once) in a PC cannot be unfinalised.
  - A DVD-RW disc that has been recorded in Video Mode of a different maker's recorder cannot be unfinalised.
  - A DVD-R disc cannot be unfinalised.
- An additional recording could be failed in the same recorder of SAMSUNG.

Downloaded From Disc-Player.com Samsung Manuals

<DVD-RW>



Recording Formats

When you insert an unused disc, the following message appears. Since available functions differ depending on the disc type, select a disc that best fits your preferences.

DVD-RAM : Formatting will be started automatically.

DVD-RW : Use after initialising the disc.
If you want to change the VR or V mode, refer to Formatting a Disc on page 100.

DVD-R : Formatting disc is unnecessary and only V Mode Recording is supported.

DVD-RAM/-RW(VR mode)

- This mode allows multiple editing functions (such as deletion of the whole title, partial deletion of a title, etc.).
- Various editing options using a created Playlist.

DVD-RW(V mode)/-R

- Chapters will be created automatically when you finalise recording on DVD-RW/-R discs in V mode.
  The chapter's length (interval between chapters) varies according to the recording mode.
- Simple editing (erasing titles/changing title name).

Downloaded From Disc-Player.com Samsung Manuals

Recording Mode

Select one of four recording modes by pressing the REC MODE button repeatedly while the unit is in Stop mode for the desired recording time and picture quality. In general, picture quality improves as the recording time decreases. In FR mode, the most suitable record mode is adjusted automatically, according to remaining time on the disc and length of the timer recording. This function is selected only one mode in XP, SP, LP and EP modes and you can use this mode for timer recording.

• DVD-SH853

Recording Mode	Recording Times	
	HDD (160GB)	DVD-RAM/-RW/-R
XP (high quality mode)	Approx. 41 hours	Approx. 1 hour about 8.5 Mbps
SP (standard quality mode)	Approx. 67 hours	Approx. 2 hours about 4.5 Mbps
LP (long recording mode)	Approx. 133 hours	Approx. 4 hours about 2 Mbps
EP (extended mode)	Approx. 199 hours Approx. 264 hours	Approx. 6 hours/ about 1.6 Mbps Approx. 8 hours/ about 1.2 Mbps
FR (Flexible Recording)	Approx. 41 hours ~ 264 hours	Approx. 1~8 hours

• DVD-SH855

Recording Mode	Recording Times	
	HDD (250GB)	DVD-RAM/±RW/±R
XP (high quality mode)	Approx. 64 hours	Approx. 1 hour about 8.5 Mbps
SP (standard quality mode)	Approx. 106 hours	Approx. 2 hours about 4.5 Mbps
LP (long recording mode)	Approx. 211 hours	Approx. 4 hours about 2 Mbps
EP (extended mode)	Approx. 316 hours Approx. 421 hours	Approx. 6 hours/ about 1.6 Mbps Approx. 8 hours/ about 1.2 Mbps
FR (Flexible Recording)	Approx. 64 hours ~ 421 hours	Approx. 1~8 hours

- Recording time may vary according to specific conditions.
- 1GB = 1,000,000,000 bytes; actual formatted capacity may be less as the internal firmware uses a portion of the memory.
- The dual layer DVD-Rs have approximately double the capacity of single layer DVD-Rs. (See page 43)
- DVB-T recording is possible only on FR mode.
- On DVB-T recording, recording mode will be automatically determined depending on the quality of the video (or audio).

Downloaded From Disc-Player.com Samsung Manuals



Unrecordable pictures

Video with copy protection cannot be recorded on this HDD & DVD Recorder.
When the HDD & DVD Recorder receives a copy- guard signal while recording, recording stops and the following message appears on the screen.

Concerning Copy Control Signals

TV broadcasts that contain copy control signals may have one of the following three signal types, Copy-Free, Copy-Once and Copy-Never. If you want to record a copy-once type programme, use DVD-RW with CPRM in VR Mode and DVD-RAM.

Signal type / Media	Copy-Free	Copy-Once	Copy-Never
DVD-RW(Ver.1.1)	O	–	–
DVD-RW(Ver.1.1) with CPRM			
VR mode	O	O*	–
V mode	O		–
DVD-R	O		–
DVD-RAM(Ver. 2.0)	O	O*	–
HDD	O	O*	–

Once "Copy Once" has been recorded, recording cannot be done anymore.

◆ Content Protection for Recordable Media (CPRM)

CPRM is a mechanism that ties a recording to the media on which it is recorded. It is supported by some HDD & DVD Recorders, but not by many DVD players. Each blank recordable DVD has a unique 64-bit media ID etched in the BCA. When protected content is recorded onto the disc, it can be encrypted with a 56-bit C2 (Cryptomeria) cipher derived from the media ID.
During playback, the ID is read from the BCA and used to generate a key to decrypt the contents of the disc. If the contents of the disc are copied to other media, the ID will be absent or wrong and the data will not be decryptable.

Downloaded From Disc-Player.com Samsung Manuals

Recording immediately

HDD DVD-RAM DVD-RW DVD-R

Before you start

1. Check that the disc has enough available space for the recording.
2. Press the **HDD** or **DVD** button.
   If you select DVD, Press the **OPEN/CLOSE** button and place a recordable disc on the disc tray.
   Press the **OPEN/CLOSE** button to close the disc tray.
   Wait until **LOAD** disappears from the front panel display.

Recording the current TV programme you are watching

1. Press the **PROG** (∨ ∧) or number buttons to select the current programme you want to record.
2. Press the **REC MODE** button repeatedly, (or press the **REC MODE** button and then press the ▲▼ buttons) to select the recording speed(quality).

   → **SP** → **LP** → **EP** → **XP**
3. Press the **REC** button.
   Information concerning the channel is displayed on the screen, then recording begins.
   Icon(◯) is displayed on the front panel.

Recording from external equipment you are watching

1. Press the **INPUT SEL.** button to select the input source according to the connection you made.
   The front panel display changes in the following sequence:

   → **PR Number** → **AV1** → **AV2** → **DV**

   If you connect a digital camcorder, press the **INPUT SEL.** button to select **DV**. (See page 69)
2. Press the **REC MODE** button repeatedly, (or press the **REC MODE** button, then press the ▲▼ buttons) to select the recording speed (quality).

   → **SP** → **LP** → **EP** → **XP**

Downloaded From Disc-Player.com Samsung Manuals

3. Press the **REC** button.
Information concerning the external input mode is displayed on the screen, then recording begins. Icon(◯) is displayed on the front panel.

To pause recording

- Press the **REC PAUSE** button to pause a recording in progress.
- Press the **REC PAUSE** button again during pause to resume recording.
- You can switch channels by pressing the **PROG** (∨ ∧) buttons while recording pauses. (Analogue broadcasting only)

- In DTV mode, if you press the REC PAUSE button:
  - The channel will not be switched and the TV/RADIO key is disabled.
  - Switching to the analog channel or changing the input source will be applied after the recording is stopped.
- In ANALOG mode, if you press the REC PAUSE button:
  - Switching to DTV mode will be applied after the recording is stopped.

To stop recording

Press the **STOP** (■) button to stop or finish a recording in progress.

- When using DVD-RAM/-RW/-R discs, the message "Updating the information of disc. Please wait for a moment" is displayed.

- You can not change the recording mode while recording.
- Recording will stop automatically if there is no free space left for recording.
- Up to 99 titles can be recorded onto a DVD-RAM/-RW/-R disc.
- Up to 999 titles can be registered on the HDD.
- HDD recording is available for up to 24 hours, and when recording for 24 hours, 3 titles will be recorded with each being 8 hours in length.
- Recording will stop automatically if a copy protected image is selected.
- DVD-RAM/-RW discs must be formatted before starting to record. Most new discs are sold unformatted.
- Do not use DVD-R authoring discs with this unit.

Downloaded From Disc-Player.com Samsung Manuals

Copying from a Camcorder

HDD DVD-RAM DVD-RW DVD-R

You may control the Camcorder using the IEEE1394 (DV) interface.

1. Connect the DV output jack of your camcorder to the DV input jack on the front of your HDD & DVD Recorder using a DV cable.
2. Press the **HDD** or **DVD** button.
   If you select DVD, press the **OPEN/CLOSE** button and place a recordable disc on the disc tray. Press the **OPEN/CLOSE** button to close the disc tray. Wait until **LOAD** disappears from the front panel display.
3. Press the **REC MODE** button repeatedly to select the recording speed(quality).

   SP → LP → EP → XP
4. Press the **INPUT SEL.** button to select **DV**.
   If the input is set to DV, a playback/record menu that enables camcorder control appears on the top of the screen.
5. Select the Play (►) icon on the upper part of the screen to playback the camcorder and find the starting position to copy.
6. To start recording, use the ◄► buttons to select Record (●) icon in the top side of the screen, then press the **OK** button.
   You can press the **REC** button of the remote control to start recording.

To stop recording

Press the **STOP** (■) button to stop or finish a recording in progress.

- When using DVD-RAM/-RW/-R discs, the message "Updating the information of disc. Please wait for a moment" is displayed.

■ To display playback related icons on the screen, press any direction button on the remote control.

Downloaded From Disc-Player.com Samsung Manuals



Making a One Touch Recording (OTR)

HDD DVD-RAM DVD-RW DVD-R

You can set the HDD & DVD Recorder to record in 30-minute increments up to 8 hours by pressing the REC button.

1. Press the **HDD** or **DVD** button.
   If you select DVD, press the **OPEN/CLOSE** button and place a recordable disc on the disc tray. Press the **OPEN/CLOSE** button to close the disc tray. Wait until **LOAD** disappears from the front panel display.
2. Press the **PROG** (∨ ∧) or number buttons to select the programme to record. If you want to record through a connected external component, press the **INPUT SEL.** button to select an appropriate external input(AV1, AV2, DV or PR01).
3. Press the **REC** button to start recording.
4. Press the **REC** button repeatedly to adjust the desired recording time.

   → **0:30** → **1:00** → **... 8:00** → **Off**

■ The timer counter decreases by the minute from 8:00 to 0:00, then the HDD & DVD Recorder stops recording.

To stop recording

Press the **STOP** (■) button. The message "Do you want to stop recording?" is displayed.

- Press the ◄► buttons to select **Yes**, then press the **OK** button.
- Or press the **STOP** (■) button again.

Downloaded From Disc-Player.com Samsung Manuals

Simultaneous Recording and Playback

HDD

You can play back from the beginning of the programme you are currently recording.
You can watching the previous title list while recording a programme.

Using the PLAY (⏯) button



1. With the unit in recording mode, press the **PLAY** (⏯) button.
   It plays back the title that you are currently recording from the beginning.
   Playback is not available for 10 seconds from the start of recording.
   You can use the **SKIP** (⏮ ⏭) and other playback-related buttons to view the previous recorded list.

Stopping Playback / Recording

1. Press the **STOP** (■) button. Playback screen disappears and the recording in progress screen appears.
2. Pressing the **STOP** (■) button once more will stop the recording.

Using the TITLE LIST button



1. With the unit in recording mode, press the **TITLE LIST** button.
   The above operation is possible from approx.10 seconds or more after recording starts.
   Press the ▲▼/**SKIP** (⏮ ⏭) buttons to select the recording title list.
2. Press the **OK** or **PLAY** (⏯) button.
   It plays back the title that you are currently recording from the beginning.

Using the MENU button



1. With the unit in recording mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Title**, then press the **OK** button.
   Title List screen is displayed.
3. Press the ▲▼/**SKIP** (⏮ ⏭) buttons to select the recording title list, then press the **OK** or ► button.
   It plays back the title that you are currently recording from the beginning.

Stopping Playback / Recording

1. Press the **STOP** (■) button once, playback screen disappears and the Title List screen appears.
2. Pressing the **MENU** (MENU) button again, the recording in progress screen appears.
3. Pressing the **STOP** (■) button once more will stop the recording.

Downloaded From Disc-Player.com Samsung Manuals

- No sound is heard during search mode.
- DVD disc or HDD playback is available during HDD recording. However, JPEG, MP3, and DivX files in the disc cannot be played back.
- HDD playback is available during DVD recording. However, JPEG and MP3 files in the HDD cannot be played back.

Time Shift function as a live signal

HDD

This function replays recordings as a live signal.
If you are interrupted while watching a TV programme, simply press the TIME SHIFT button, and the HDD & DVD Recorder immediately starts recording the programme.

Using the Time Shift function



1. Press the **TIME SHIFT** button on the remote control.
   The Time Shift menu is displayed.
2. Press the ▲▼ button to select **On**, then press the **OK** button.
3. While watching the currently broadcasting programme, press the **PLAY/PAUSE** (⏯) button.
   The programme on TV is set in pause mode and the Time Shift Bar is displayed.
4. Press the **PLAY/PAUSE** (⏯) button again to resume watching the programme.

◆ Time Shift Screen Elements

1. Displays the current media.
2. Displays the current status.
3. Watching Point.
4. Current play time.
5. Live Point.
6. Live Time.
7. Time Shift Time Bar

Buttons on the Remote Control used for Time Shift function

1. **PLAY/PAUSE** (⏯) button : Pause live TV and resumes playback.
2. **SEARCH** (⏪⏩) buttons : Fast play (X 2, X 4, X 8, X 16, X 32, X 128)
3. **SKIP** (⏭) button, **STOP** (■) button : Switches to live TV.
4. **SKIP** (⏮) button : Returns to the point where Time Shift begines.

- The Time Shift is available only when HDD mode is selected.
- You can use this function for up to maximum two hours.
- You can only play the contents by using the menu when the Time Shift is set to On.
- Press **TIME SHIFT** button to cancel the Time shift function.

Downloaded From Disc-Player.com Samsung Manuals

Making a Timer Recording

HDD DVD-RAM DVD-RW DVD-R

1. **Check the antenna cable is connected.**
2. **Check the remaining time of the disc.**
3. **Check the date and time are correct.**

Make sure the Clock (Setup-Clock Set) must be set before you proceed with a timer recording. (See pages 26~27)





Using the TIMER button

1. With the unit in Stop mode, press the **TIMER** button.
2. Press the **OK** or ► button to select **Scheduled List**.
3. Press the **OK** button to select **Add a list**.
4. Set timer recording option.
   - Fill the input items using the ▲▼◄► buttons and number buttons.
     ◄► : Moves to the previous/next item.
     ▲▼, 0~9 : Sets a value.
   - **To** : Select the media to record HDD or DVD.
   - **Source** : The video input source (AV1, AV2), or the broadcasting channel you want to make a timer recording from.
     To convert DTV/Analogue, press DTV/ANALOG button of the remote control.
     On the DTV mode, you can change TV or RADIO by pressing the TV/RADIO button on the remote control.
   - **Date** : Timer Recording allows setting the recording time within one month period. Set the recording day. (month/day)



   - Start/End Time : Start and end time of the timer recording.
   - Mode (Recording Mode) :
     - FR (Flexible Recording) : Select when you want to set video quality automatically. In FR mode, the most suitable record mode is adjusted automatically, according to remaining time on the disc and length of the timer recording. This function is selected only one mode in XP, SP, LP and EP modes.
     - XP (high quality) : Select when video quality is important.
     - SP (standard quality) : Select to record in standard quality.
     - LP (low quality) : Select when a long recording time is required.
     - EP (extended) : Select when a longer recording time is required.
     - The dual layer DVD-Rs have approximately double the capacity of single layer DVD-Rs. (See page 43)

Downloaded From Disc-Player.com Samsung Manuals

- When you are recording at EP mode on a DVD-RW(V mode)/-R disc, it may not record the full 6 or 8 hours because the unit uses the VBR(Variable Bit Rate) ENCODING system. For example, if you record a programme with a lot of action, it uses a higher bit rate which in turn consumes more disc memory.
- DVB-T Timer recording is possible only on FR mode.
- On DVB-T recording, recording mode will be automatically determined depending on the quality of the video (or audio).

• **TITLE** : To label the title name, press the **RED(A)** button.
Title renaming screen appears.
Follow steps 4 and 5 of "Renaming (Labeling) a Title" on page 80.

5. After selecting the set up value for each mode, press the **OK** button to select **Save**.
• ◴ will appear on the front panel. It means that a timer recording is registered.

If the timer settings overlap;
The programmes are recorded in order of priority. After recording of the first programme is complete, the second programme starts being recorded.

To exit without saving the current setting
Press the **EXIT ( )** button.

To return to the previous menu
Press the **RETURN** button if you don't want to set a timer recording.

6. When you want to recording on DVD-RAM/-RW/-R, you must insert the disc.

7. Turn the power off to finish the Timer Recording setting.
Timer Recording will not work when the power is on.

- The timer recording time may differ from the set time depending on disc status and overall timer recording status (for example, recording times overlapping, or when the previous recording ends within 2 minutes before the start time of the next recording.)
- You can make the Timer Recording up to 12 programmes.
- If HDD disk has no available recording space, ◴ blinks. It means that HDD disk has no space to record.

Downloaded From Disc-Player.com Samsung Manuals





Editing the Scheduled List

Follow these directions to edit the Scheduled List.

Using the TIMER button

1. With the unit in Stop mode, press the **TIMER** button.
2. Press the **OK** or ► button to select **Scheduled List**.
3. Press the ▲▼ buttons to select the number of the Scheduled List you want to edit, then press the **OK** button.
   - Edit the items you want to modify. See the "Making a Timer Recording" section for more information on Timer Recording Input items. (See pages 73~74)
4. Press the **OK** button to confirm the edited setting.
5. Press the **EXIT (⏻)** button after finishing the operation.
   The Scheduled List screen will disappear.

Adding a Scheduled List

Follow these directions to add an entry from the Scheduled List.







Using the TIMER button

1. With the unit in Stop mode, press the **TIMER** button.
2. Press the **OK** or ► button to select **Scheduled List**.
3. Press the ▲▼ buttons to select the number of the Scheduled List, then press the **RED(A)** button.
   - Set the items you want to add. See the "Making a Timer Recording" section for more information on Timer Recording Input items. (See pages 73~74)
4. Press the **OK** button to confirm the added setting.
5. Press the **EXIT (⏻)** button after finishing the operation.
   The Scheduled List screen will disappear.

Downloaded From Disc-Player.com Samsung Manuals





Deleting a Scheduled List

HDD DVD-RAM DVD-RW DVD-R

Follow these directions to delete an entry from the Scheduled List.

Using the TIMER button

1. With the unit in Stop mode, press the **TIMER** button.
2. Press the **OK** or ► button to select **Scheduled List**.
3. Press the ▲▼ buttons to select the number of the Scheduled List you want to delete, and then press the **GREEN(B)** button.
   - You will be prompted with the delete confirm message such as "Do you want to delete?".
4. Press the ◄► buttons to select **Yes**, then press the **OK** button.
   - The selected entry will be deleted from the list.
5. Press the **EXIT** (⏻) button after finishing the operation.
   The Scheduled List screen will disappear.

Downloaded From Disc-Player.com Samsung Manuals

Using the G-Code Feature



HDD DVD-RAM DVD-RW DVD-R

Before presetting your HDD & DVD Recorder.

- ***Switch on both the television and your HDD & DVD Recorder.***
- ***Check that the date and time are correct.***

Up to twelve programmes can be preset

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Timer Record**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **G-Code**, then press the **OK** or ► button.
   - A message is displayed to allow you to enter the G-Code code.
4. Press the number buttons to enter the code of the programme that you want to record in your television magazine.
   - If you want to correct the G-Code code that you are entering:
     - Press the ◄ button until the digit to be corrected is cleared.
     - Enter the correct digit.
5. Press the **OK** button.
   - The information concerning the programme is displayed.
   - When using the G-Code function for the first time with stored stations, the programme number flashes. This one time, you must enter the PR number manually by pressing the ▲▼ buttons.
6. Press the **RED(A)** button if you do not want to use the default title name.
   The rename screen is displayed.
   Follow steps 4 and 5 of "**Renaming (Labeling) a Title**" on page 80.
7. If the programme and times are correct, press the **OK** button.
8. Turn the power off by pressing the **STANDBY/ON** button to activate the timer recording setting.
   - Refer to pages 73~74 if you want to
     - Check whether the timer Recording has set correctly or not.
     - Cancel a preset recording.

- The numbers next to each TV programme listing in the magazines or newspapers are G-Code code numbers, which allow you to programme your HDD & DVD Recorder. instantly with the remote control. Enter the G-Code code for the programme you wish to record.
- G-Code is a trademark of Gemstar Development Corporation. The G-Code system is manufactured under licence from Gemstar Development Corporation.

Downloaded From Disc-Player.com Samsung Manuals

G-Code Extended



To prevent delays or overruns the HDD & DVD Recorder has a function called G-Code Extended allowing you to extended the recording time by up to 60 minutes.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Timer Record**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **G-Code Extended**, then press the **OK** or ► button.
4. Press the ▲▼ buttons to select the G-Code Extended time, then the press **OK** or ► button.
5. Press the **EXIT** (⏻) button to exit the menu.

Go To Recorded List




HDD
Recorded List
No. To Source Date Start End Mode Status
01 HDD PR 01 JAN 01 17:30 18:30 SP OK
02 HDD PR 01 JAN 01 21:00 22:00 SP OK
03 HDD PR 01 JAN 01 23:15 23:45 SP OK
A Delete
B Delete All
C Scheduled List
MOVE
SELECT
RETURN
EXIT

HDD DVD-RAM DVD-RW DVD-R

You can confirm the performance results of title lists that have passed the reserved recording time.

Using the TIMER button

1. With the unit in Stop mode, press the **TIMER** button.
2. Press the ▲▼ button to select **Recorded List**, then press the **OK** or ► button.
3. Press the **EXIT** (⏻) button after finishing the operation. The Recorded List screen will disappear.

Information about Recorded List



Informs whether the selected Recorded List performed a Timer Recording successfully.

3-1. Press the ▲▼ buttons to select the number of the **Recorded List**, then press the **OK** button.

Downloaded From Disc-Player.com Samsung Manuals

Delete Recorded List



Deletes a Recorded List individually.

3-1. Press the ▲▼ buttons to select the number of the **Recorded List** you want to delete, and then press the **RED(A)** button.

4. Press the ◄► buttons to select **Yes**, then press the **OK** button.

Clear Recorded List



Clears all Recorded List at once.

3-1. Press the **GREEN(B)** button.

4. Press the ◄► buttons to select **Yes**, then press the **OK** button.

Go to Scheduled List


HDD
Recorded List
No. To Source Date Start End Mode Status
01 HDD PR 01 JAN 01 17:30 18:30 SP OK
02 HDD PR 01 JAN 01 21:00 22:00 SP OK
03 HDD PR 01 JAN 01 23:15 23:45 SP OK
A Delete
B Delete All
Scheduled List
MOVE
SELECT
RETURN
EXIT



Switches directly from the Recorded List to the Scheduled List.

3-1. Press the **YELLOW(C)** button.

Downloaded From Disc-Player.com Samsung Manuals

Editing

This section introduces basic functions of editing and explains both edit functions for the recording on a disc and edit functions for the entire disc.

Recording or editing might not be completed if an error, such as a sudden power failure occurs.
Please be aware that a material that has been damaged is unable to be retrieved to its original content.

Basic Editing (Title List)

Playing the Title

HDD DVD-RAM DVD-RW DVD-R



Follow these instructions to play back a scene from the Title List.

Using the TITLE LIST button

1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the ▲▼ buttons to select an entry you want to play from Title List, then press the **OK** or **PLAY** (⏯) button.
   The selected entry (title) will be played back.
3. To stop title play, press the **STOP**(■) button.
   The screen returns to the Title List screen.

Renaming (Labeling) a Title

HDD DVD-RAM DVD-RW DVD-R



Follow these instructions to rename a title list entry, i.e., to edit the title of a recorded programme.

Using the TITLE LIST button

1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the ▲▼ buttons to select an entry you want to rename from the Title List, then press the **RED(A)** button.
3. Press the ▲▼ buttons to select **Rename**, then press the **OK** or ► button.
   The Rename screen is displayed.
4. Select the desired characters using the ▲▼◄► buttons, press the **OK** button.
   - **Back Space (RED(A) button)** : Deletes and moves the cursor backwards by one position.
   - **Space (GREEN(B) button)** : Enters a blank and moves the cursor one forward (to the right).

Downloaded From Disc-Player.com Samsung Manuals



- **Clear (YELLOW(C) button)** : Deletes all the character inputs.
- **Save (BLUE(D) button)** : Registers the character inputs.

5. Press the **BLUE(D)** button to select **Save**.
   The changed title name is displayed on the title item of the selected entry.

Locking (Protecting) a Title

HDD DVD-RAM DVD-RW DVD-R

Follow these instructions to lock an entry to protect it from accidental deletion.

Using the TITLE LIST button



1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the ▲▼ buttons to select an entry you want to protect from the Title List, then press the **MARKER** button until a checkmark appears. Repeat this step to select an additional title you want to protect.
   - If you don't want to protect a certain one of the checked entries, simply select that entry and press the MARKER to deselect it until a checkmark disappears.
3. Press the **RED(A)** button to select **Edit**.
   Edit menu is displayed.



4. Press the ▲▼ buttons to select **Protection**, then press the **OK** or ► button.
5. Press the ◄► buttons to select **On**, then press the **OK** button.
   The key icon on the information window for the selected entry changes to the locked status. (🔓→🔒)
6. If you want to cancel the Protection, select **Off** in step 5 and press the **OK** button. The key icon changes to the unlocked status. (🔒→🔓)



■ If you select "Select All" in the Edit menu, all title will be checked.

Downloaded From Disc-Player.com Samsung Manuals





Deleting a Title

HDD DVD-RAM DVD-RW DVD-R

Follow these instructions to delete an entry from the Title List.

Using the TITLE LIST button

1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the ▲▼ buttons to select an entry you want to delete in the Title List, then press the **MARKER** button until a checkmark appears. Repeat this step to select an additional title you want to delete.
   - If you don't want to delete a certain one of the checked entries, simply select that entry and press the **MARKER** to deselect it until a checkmark disappears.
3. Press the **RED(A)** button to select **Edit**.
   Edit menu is displayed.
4. Press the ▲▼ buttons to select **Delete**, then press the **OK** or ► button.
   - The message may be different depending on the type of disc. You will be prompted with the confirmation message.
     HDD, DVD-RAM(VR mode), DVD-RW(VR mode) : The message "Do you want to delete? (Related playlists may be deleted.)" is displayed.
     DVD-RW(V mode)/-R : The message "Do you want to delete?" is displayed.
5. Press the ◄► buttons to select **Yes**, then press the **OK** button.

- You cannot delete a protected entry. If you want to delete a protected entry, select "Off" in the Title Protection menu.
  (See page 81)
- When the Disc Protection has been set to Protected, you cannot delete titles.
  (See page 98)
- Once an entry is deleted from the Title List it cannot be recovered.
- Once DVD-RW/-R is finalised, it cannot be deleted.
- With DVD-R, titles are only deleted from the menu, however, the Title remains physically on the disc.
- If you select "Select All" in the Edit menu, all title will be checked.

Downloaded From Disc-Player.com Samsung Manuals









Splitting a Section of a Title (Split)

HDD

Follow these instructions to split a section of a Title List entry into two titles.

Using the TITLE LIST button

1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the ▲▼ buttons to select an entry you want to Split from the Title List, then press the **RED(A)** button.
   The Edit menu is displayed.
3. Press the ▲▼ buttons to select **Split**, then press the **OK** or ► button.
4. Using the playback-related buttons (**PLAY** (⏯), **SEARCH** (⏪⏩)), move to a point for splitting and press the **OK** button.
   If it is not the point where you want to split, press the **RETURN** button to cancel the selection. Using the playback-related buttons, move to a point to split and press the **OK** button.
   ① First split interval
   ② Current playtime
   ③ Start time of the second split and its screen
5. Press the **OK** button to select **Split**.
6. Press the ◄► buttons to select **Yes**, then press the **OK** button.
   The split title is divided into two, and the following titles will be shifted down by one.

Editing

Downloaded From Disc-Player.com Samsung Manuals



Deleting a Section of a Title (Partial Delete)

HDD DVD-RAM DVD-RW

(VR mode)

Follow these instructions to delete a section of a Title List entry.

Using the TITLE LIST button

1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the ▲▼ buttons to select an entry you want to edit from the Title List, then press the **RED(A)** button.
   The Edit menu is displayed.
3. Press the ▲▼ buttons to select **Partial Delete**, then press the **OK** or ► button.
4. Press the **OK** button at the starting point.
   The image and starting point time is displayed in the section deletion starting point window.
   Partial Delete List Screen Elements
   ① Playback bar
   ② Playtime
   ③ Section deletion starting point window and time
   ④ Section deletion end point window and time
   - Select the start and end points of the section you want to delete using the playback related buttons.
   - Playback related buttons : (**PLAY** (⏯), **SEARCH** (⏪⏩)).
5. Press the **OK** button at the end point.
   The image and end point time is displayed in the Section deletion ending point window.
6. Press the ◄► buttons to select **Delete**, then Press the **OK** button.
7. Press the ◄► buttons to select **Yes**, then press the **OK** button.
   The selected section has been deleted.
8. Press the ◄► buttons to select **Return**, then press the **OK** button to finish the operation.

- The length of the section to be deleted must be at least 5 seconds long.
- End point cannot be marked earlier than start point
- The section cannot be deleted when it includes a still picture.
- Press the **EXIT** (⏏) button after the operation has finished.
  The Title List screen will disappear.

Editing

Downloaded From Disc-Player.com Samsung Manuals



Using the Sort function (Title List)

HDD DVD-RAM DVD-RW DVD-R

When you need to change the Sort order of Title List, you can change it simply.
You can sort by Date, Name, Length, Channel info. Sorted list will be resorted in chronical order upon reentering Title List.

1. While the list menu is displayed, press the **GREEN(B)** button to select **Sort**.
2. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.
   - **Date** : In order of when the titles were recorded
   - **Name** : In alphabetical order
   - **Length** : In order of recorded title length.
   - **Channel Info** : In order of Channel information.

■ You can sort by Date, Name, Length, Channel info. Sorted list will be resorted in copied order upon reentering Title List.

Navigation Menu







Time Navigation

HDD DVD-RAM DVD-RW
(VR mode)

Using this function, you can search scene minute-by-minute from the recorded title list.

Using the TITLE LIST button

1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the ▲▼ buttons to select an entry you want to play from Title List, then press the **YELLOW(C)** button.
3. Press the ▲▼ buttons to select **Time Navigation**, then press the **OK** or ► button.
4. Press the ◄► buttons to skip one minute at a time and search the desired scene, then press the **OK** or **PLAY** (⏯) button.

■ Cursor does not move if the selected recorded title is shorter than 1 minute.

■ The Navigation function may not work on a disc that has not been recorded by this device.

■ An edited title may not display the exact search time.

Downloaded From Disc-Player.com Samsung Manuals







Scene Navigation

HDD DVD-RAM DVD-RW

(VR mode)

If there is a title composed of markers (See page 53), you can search the desired scene using the Scene Navigation.

Using the TITLE LIST button

1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the ▲▼ buttons to select an entry you want to play from Title List, then press the **YELLOW(C)** button.
3. Press the ▲▼ buttons to select **Scene Navigation**, then press the **OK** or ► button.
4. Press the ▲▼◄► buttons to select desired scene, then press the **OK** or **PLAY** (⏯) button.

■ Scene Navigation will not operate if a selected title does not have Markers.

Select Contents

HDD DVD-RAM DVD-RW DVD+R

1. Press the **BLUE(D)** button to select **Contents**.
2. Press the ▲▼ buttons to select the contents you want to move, then Press the **OK** or ► button.

■ This function is possible only when the disc contains the selected contents.

Downloaded From Disc-Player.com Samsung Manuals

Creating a Playlist

HDD DVD-RAM DVD-RW
(VR mode)

Follow these instructions to create a new playlist entry from a recorded title.







Using the TITLE LIST button

1. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
2. Press the **RED(A)** button.
   The Edit menu is displayed.
3. Press the ▲▼ buttons to select **New Playlist**, then press the **OK** or ► button.
   The Make Playlist screen is displayed.
4. Press the **OK** button at the start point.
   - The image and time at the start point is displayed on the Start window.
   - The yellow-coloured selection bar moves to the **End** item.
   - Select the starting point of the section from which you want to create a new scene using the playback related buttons (**PLAY** (⏯), **SEARCH** (⏪⏩), **SKIP** (⏮⏭)).
5. Press the **OK** button at the end point.
   - The image and end point time is displayed in the **End** window.
   - The yellow-coloured selection bar moves to the **Make** item.
6. Press the ◄► buttons to select **Make**, then press the **OK** button.
   - To make a scene for the playlist.
     A new Make scene screen is displayed. Repeat steps 4~6 to make a new scene for the playlist.
     A new scene will be added to the current playlist.
     You can check and see all the scenes on the Edit playlist screen. (See pages 89~91)
   - To make a new playlist.
     Repeat steps 1~6 if you want to make a new playlist.
7. Press the ◄► button to select **Return**, then press the **OK** button to finish the operation.

- You can create up to 99 playlist entries.
- Depending on the kind of disc, the displayed screen may have a slight difference.
- If the related title is erased, the playlist is also erased.

Downloaded From Disc-Player.com Samsung Manuals



Playing Entries in the Playlist

HDD DVD-RAM DVD-RW
(VR mode)

Follow these instructions to play the playlist entries.

Using the PLAY LIST button

1. With the unit in Stop mode/Playback mode, press the **PLAY LIST** button.
2. Press the ▲▼ buttons to select the playlist you want to play, then press the **OK** or **PLAY** (⏯) button.
3. Press the **STOP** (⏹) button to stop playing.
   The screen returns to the Playlist screen.





Renaming a Playlist Entry

HDD DVD-RAM DVD-RW
(VR mode)

Follow these instructions to rename a playlist entry, i.e. to edit the title of a playlist entry.

Using the PLAY LIST button

1. With the unit in Stop mode/Playback mode, press the **PLAY LIST** button.
2. Press the ▲▼ buttons to select the title you want to Rename from the Playlist, then press the **RED(A)** button.
   The Edit menu is displayed.
3. Press the ▲▼ buttons to select **Rename**, then press the **OK** or ► button.
   The Rename screen is displayed.
4. Select the desired characters using the ▲▼◄► buttons, then press the **OK** button.
   - **Back Space (RED(A) button)** : Deletes and moves the cursor backwards by one position.
   - **Space (GREEN(B) button)** : Enters a blank and moves the cursor one forward (to the right).
   - **Clear (YELLOW(C) button)** : Deletes all the character inputs.
   - **Save (BLUE(D) button)** : Registers the character inputs.
5. Press the **BLUE(D)** button to select **Save**.
   The changed title is displayed in the title field of the selected playlist entry.

Downloaded From Disc-Player.com Samsung Manuals







Editing a Scene for the Playlist

HDD DVD-RAM DVD-RW
(VR mode)

Follow these instructions to edit scenes for a playlist.

Using the PLAY LIST button

1. With the unit in Stop mode/Playback mode, press the **PLAY LIST** button.
2. Press the ▲▼ buttons to select the title you want to edit from the Playlist, then press the **RED(A)** button.
   The Edit menu is displayed.
3. Press the ▲▼ buttons to select **Edit Playlist**, then press the **OK** or ► button.
   The Edit Playlist screen is displayed.

Playing a Selected Scene

4. Press the ▲▼◄► buttons to select the scene you want to play, then press the **OK** or **PLAY** (⏯) button.
   The selected scene is played.
   - To stop scene play, press the **STOP** (■) button.

Modifying a Scene (Replacing a Scene)

To setup, follow steps 1 to 3.





4-1. Press the ▲▼◄► buttons to select the scene you want to Modify, then press the **RED(A)** button.
   The Modify Scene screen is displayed.

5. Press the **OK** button at the start point of the scene.
   - The image and starting point time is displayed on the **Start** window.
   - Select the starting or ending point of the section you want to modify using the playback related buttons (**PLAY** (⏯), **SEARCH** (⏪⏩), **SKIP** (⏮⏭)).

Downloaded From Disc-Player.com Samsung Manuals



6. Press the **OK** button at the end point of the scene.
   - The image and ending point time is displayed in the End window.
7. Press the ◄► buttons to select **Change**, then press the **OK** button.
   - The scene you want to modify is changed with the selected section.

Moving a Scene (Changing the Position of a Scene)

To setup, follow steps 1 to 3 in page 89.





4-1. Press the ▲▼◄► buttons to select the scene you want to move (change the position), then press the **GREEN(B)** button.
   - A yellow selection window is displayed on the scene to be moved.
5. Press the ▲▼◄► buttons to select the position to which you want to move the selected scene, then select the **OK** button.

- You cannot move the selected scene to the position of the next scene, because the selected scene should be inserted before that position, which requires no action.
- Depending on the kind of disc, the displayed screen may have a slight difference.

Adding a Scene

To setup, follow steps 1 to 3 in page 89.







4-1. Press the ▲▼◄► buttons to select the scene that will have a new scene inserted before it, then press the **YELLOW(C)** button.
The Add Scene screen is displayed.
5. Press the **OK** button at the starting point of the scene.
   - The image and starting point time is displayed on the **Start** window.
   - Select the starting or ending point of the section you want to modify using the playback related buttons (**PLAY** (⏯), **SEARCH** (⏪⏩), **SKIP** (⏮⏭)).
6. Press the **OK** button at the end point of the scene.
   - The image and end point time are displayed in the **End** window.
   - To cancel, press the ◄► buttons to select **Return**, then press the **OK** button.
7. Press the ◄► buttons to select **Add**, then press the **OK** button.
   - The section you want to add is inserted prior to the scene selected in step **4-1** of Adding a Scene.

Downloaded From Disc-Player.com Samsung Manuals





Deleting a Scene

To setup, follow steps 1 to 3 in page 89.

4-1. Press the ▲▼◄► buttons to select the scene you want to delete, then press the **BLUE(D)** button.

- The message "Do you want to delete the scene?" is displayed.

5. Press the ◄► buttons to select **Yes**, then press the **OK** to delete the selected scene.

Deleting a Playlist Entry from the Playlist







Using the PLAY LIST button

1. With the unit in Stop mode/Playback mode, press the **PLAY LIST** button.

2. Press the ▲▼ buttons to select an entry you want to delete in the **Playlist**, then press the **MARKER** button until a checkmark appears. Repeat this step to select an additional title you want to delete.

- If you don't want to delete a certain one of the checked entries, simply select that entry and press the MARKER to deselect it until a checkmark disappears.

3. Press the **RED(A)** button to select **Edit**.
Edit menu is displayed.

4. Press the ▲▼ buttons to select **Delete**, then press the **OK** or ► button.

- You will be prompted with the delete confirmation message "Do you want to delete?".

5. Press the ◄► buttons to select **Yes**, then press the **OK** button.
You will be automatically returned to the Playlist screen after the delete operation has finished.

■ If you select "Select All" in the Edit menu, all title will be checked.

Downloaded From Disc-Player.com Samsung Manuals



Using the Sort (Playlist)

When you need to change the Sort order of Playlist, you can change it simply.

1. While the list menu is displayed, press the **GREEN(B)** button to select **Sort**.
2. Press the ▲▼ buttons to select the desired item, then press the **OK** or ► button.
   - **Date** : In order of when the playlists were created
   - **Name** : In alphabetical order

■ You can sort by Date, Name. Sorted list will be resorted in copied order upon reentering Playlist.

Copying from HDD to DVD

About the Copy Screen



① Total size and number of selected titles for copying
② Title to be copied
③ This shows available disc space
④ The location where the copied files are stored
⑤ Copy start button
⑥ Sort button (Date, Name, Length, Channel Info)
⑦ Selection button
- **Select All** : All entries in the current folder will be checked.
- **Unselect All** : All checked entries will be unchecked.

Contents Copy Specifications

Contents	HDD ➞ DVD
Recorded Video Title	Supported
Copy Protected Title	Not supported
Copy Once Title	Move (Deletes the Title in the HDD after copying)

The Copy is possible only with CPRM-Compatible disc.
Once "Copy Once programme" has been recorded on the DVD disc, this title cannot be copied to HDD anymore.
But "Copy Once programme" has been recorded on the HDD, this title can be copied to DVD-RW(VR mode) or DVD-RAM.

Using the TITLE LIST button



1. Press the **OPEN/CLOSE** button and place a recordable disc on the disc tray.
2. Press the **OPEN/CLOSE** button to close the disc tray. Wait until **LOAD** disappears from the front panel display. Check that the disc has enough available space for the recording.
3. Select the HDD by pressing the **HDD** button on the front panel of the HDD & DVD Recorder or on the remote control.

Downloaded From Disc-Player.com Samsung Manuals



4. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
5. Press the **COPY** button. Copy screen is displayed.
   - During Playback, you can go to copy screen by pressing the **COPY** button.
6. Press the ▲▼ buttons to select the title you wan to copy, then press the **MARKER** button until a checkmark appears.
   Repeat this step to select an additional title you want to copy.
   - If you don't want to copy a certain one of the checked entries, simply select that entry and press **MARKER** button to deselect it until a checkmark disappears.
7. Press the **RED(A)** button to select **Start Copy**.
   - The title to be copied is not displayed on the screen, and copying begins while the currently broadcasting programme is displayed on the screen.
   - Press the **INFO** button to change the copy processing bar.
     If you press **INFO** button again, copy processing bar will be appeared.
   - To cancel the copying in progress, press the **RED(A)** button.
8. After a successful copy, "The title is successfully copied" message is displayed.

■ The noise may be occurred when copying because HDD & DVD Recorder supports high speed copying.

Downloaded From Disc-Player.com Samsung Manuals







Copying from DVD to HDD

Using the TITLE LIST button

1. Press the **OPEN/CLOSE** button and place a recorded disc on the disc tray.
2. Press the **OPEN/CLOSE** button to close the disc tray.
3. With the unit in Stop mode/Playback mode, press the **TITLE LIST** button.
4. Press the **COPY** button. Copy screen is displayed.
   - During Playback, you can go to copy screen by pressing the **COPY** button.
5. Press the ▲▼ buttons to select the title you want to copy, then press the **MARKER** button until a checkmark appears.
   Repeat this step to select an additional title you want to copy.
   - If you don't want to copy a certain one of the checked entries, simply select that entry and press **MARKER** button to deselect it until a checkmark disappears.
6. Press the **RED(A)** button to select **Start Copy**.
   - Press the **INFO** button to change the copy processing bar.
     If you press **INFO** button again, copy processing bar will be appeared.
   - To cancel the copying in progress, press the **RED(A)** button.
7. After a successful copy, "The title is successfully copied." message is displayed.

- You cannot copy anything else on finalised DVD-R and DVD-RW(V mode) mode.
- You cannot copy a DVD-VIDEO to HDD.
- The noise may be occurred when copying because HDD & DVD Recorder supports high speed copying.

Contents Copy Specifications

Contents	DVD → HDD
Recorded Video Title	Supported
Copy Protected Title	Not supported
Copy Once Title	Not supported

Downloaded From Disc-Player.com Samsung Manuals









Copying MP3, JPEG or DivX

When you copy MP3/JPEG/DivX files from HDD to DVD, only DVD-RW (V)/-R discs are available.

File Copy

1. Insert a JPEG disc, MP3 disc or DivX disc into the disc tray.
2. Press the **OPEN/CLOSE** button to close the disc tray. Wait until **LOAD** disappears from the front panel display. Check that the disc has enough available space for the recording.
3. Press the ▲▼ buttons to select **Library**, then press the **OK** or ► button.
4. Press the ▲▼ buttons to select **Music**, **Photo** or **DivX**, then press the **OK** or ► button.
5. Press the **COPY** button. Copy screen is displayed.
6. Press the ▲▼ buttons to select the MP3, Photo or DivX file you want to copy, then press the **MARKER** button until a checkmark appears.
   - If you don't want to copy a certain one of the checked entries, simply select that entry and press **MARKER** button to deselect it until a checkmark disappears.
7. Press the ► button, then press the **OK** button to make the first folder where the copied files are stored.
   - You can create a new folder by pressing the **GREEN(B)** button.
8. Press the **RED(A)** button to select **Start Copy**.
   - The message "Number of item : x" is displayed.
9. Press the ◄► buttons to select **Start**, then press the **OK** button. File copy begins.
   - To cancel the copying in progress, press the **EXIT** (⏻) button.

Folder Copy





1. Insert a Disc (JPEG, MP3 or DivX) into the tray.
2. Press the ▲▼ buttons to select **Library**, then press the **OK** or ► button.
3. Press the ▲▼ buttons to select **Music**, **Photo** or **DivX** then press the **OK** or ► button.
   MP3, JPEG or DivX folder is displayed.
4. Press the **COPY** button. Copy screen is displayed.
5. Press the ▲▼ buttons to select the folder you want to copy, then press the **MARKER** button until a checkmark appears.
   - If you don't want to copy a certain one of the checked folders, simply select that entry and press **MARKER** button to deselect it until a checkmark disappears.

Downloaded From Disc-Player.com Samsung Manuals





6. Press the ►▲▼ or **OK** button to select the location where the copied files are stored.
   - You can create a new folder by pressing the **GREEN(B)** button.
7. Press the **RED(A)** button to select **Start Copy**.
   The message "Number of item : x" is displayed.
   - The item is named the number of file that is available in the folder.
8. Press the ◄► buttons to select **Start**, then press the **OK** button.
   Folder copy begins.
   Subfolders and files in the selected folder are copied.
   - To cancel the copying in progress, press the **EXIT** (⏻) button.

- Pressing the **EXIT** (⏻) button during folder copying will cancel the folder copying after the current file is copied.
- You can copy up to 500 including fi les and sub folders to one folder. [MP3, JPEG, DivX]
- If you want to file copy, you should create a new folder before starting a copy.
  You cannot copy to top-level(ROOT) folder directly without creating a new folder.
- If the top-level (ROOT) folder has had already 500 including folders, you should delete one or more items before you can create a new folder.
- Files having an existing name of ***.mp3/***.jpg, are automatically renamed to ***01.mp3/***01.jpg and copied.
- It allows up to 999 copies to have the same name.
- You cannot copy an Audio CD.
- File size on a disc and the copied file in the HDD may be slightly different due to the file system.
- If you check some entries in the current folder and move to open a different folder, those entries are automatically unchecked and excluded from the selection list.

Contents Copy Specifications

Contents	HDD ➞ DVD	DVD ➞ HDD
MP3	Supported	Supported
JPEG(photo)	Supported	Supported
DivX	Supported	Supported

- Disc(CD-R/CD-RW/DVD-RAM/DVD-R(Finalise)/DVD-RW(Finalise)) ➞ HDD
- HDD ➞ DVD-R, DVD-RW(V)
- The disc that has Video recording or has title dubbing from HDD can't be copied.
- If the disc is finalised through Disc Manager, it can be compatible with PC as a disc with a UDF file system.

Downloaded From Disc-Player.com Samsung Manuals

Changing the name of Music/Photo/DivX file







HDD

You can rename a Music, Photo or DivX file copied to HDD.

1. Press the ▲▼ buttons to select the entry you want to rename, then press the **RED(A)** button.
2. Press the ▲▼ buttons to select **Rename**, then press the **OK** or ► button.
   Rename Screen is displayed.
3. Select the desired characters using the ▲▼◄► buttons, then press the **OK** button.
   Back Space (RED(A) button) : Deletes and moves the cursor backwards by one position.
   Space (GREEN(B) button) : Enters a blank and moves the cursor one forward (to the right).
   Clear (YELLOW(C) button) : Deletes all the character inputs.
   Save (BLUE(D) button) : Registers the character inputs.
4. Press the **BLUE(D)** button to select **Save**.
   The changed file name is displayed on the selected entry.

Downloaded From Disc-Player.com Samsung Manuals

Editing the Disc Name





DVD-RAM DVD-RW DVD-R

Follow these instructions to give a name to a disc.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Disc Manager**, then press the **OK** or ► button.
3. Press the ◄► buttons to select **Rename**, then press the **OK** button. The Rename screen is displayed.
4. Select the desired characters using the ▲▼◄► buttons, then press the **OK** button.
5. Press the **BLUE(D)** button to select **Save**. A disc name is given to the disc.

- You may need to clear Disc Protection beginning editing.
- Depending on the kind of disc, the displayed screen may be different.
- If you have recorded a DVB-T radio channel program, the time information displayed for each of free and used space may be incorrect.

Disc Protection





DVD-RAM DVD-RW DVD-R

Disc Protection allows you to protect your discs from being formatted or deleted due to unintended operations.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Disc Manager**, then press the **OK** or ► button.
3. Press the ◄► buttons to select **Protection**, then press the **OK** button.
4. Press the ◄► buttons to select **On**, then press the **OK** button.

Downloaded From Disc-Player.com Samsung Manuals

Delete All Title Lists





DVD-RAM DVD-RW DVD-R

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Disc Manager**, then press the **OK** or ► button.
3. Press the ◄► buttons to select **Delete All**, then press the **OK** button.
   - You will be prompted with the confirmation message "Do you want to delete all title lists?".
   - When Protected Entry exists: The Delete All Title List function will not operate. If there is a title containing a still picture, however, that function will not operate.
     If you want to delete a protected entry, disable Protect for it on the Lock item.
   - When protected a DVD-RAM/-RW is used, data cannot be deleted from a disc.
   - If you select **Yes**, you will be prompted with the confirmation message "All playlists will also be deleted. Do you want to continue?".
4. Press the ◄► buttons to select **Yes**, then press the **OK** button.
   All title lists are deleted.

Delete All Title Lists/DivX Lists /Music Lists/Photo Lists





<Title>



HDD

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Disc Manager**, then press the **OK** or ► button.
3. Press the ◄► buttons to select **Delete**, then press the **OK** button.
4. Press the ◄► buttons to select the **Title**, **DivX**, **Music** or **Photo**, then press the **OK** button.
5. Press the ◄► buttons to select **Yes**, then press the **OK** button.
   All title lists, DivX lists, music lists or photo lists are deleted.

Downloaded From Disc-Player.com Samsung Manuals





Formatting a Disc

HDD DVD-RAM DVD-RW

Use these instructions to format a disc.
The disc protect should also be cleared.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Disc Manager**, then press the **OK** or ► button.
3. Press the ◄► buttons to select **Format**, then press the **OK** button.

   HDD/ DVD-RAM
   - You will be prompted with the confirmation message "Current media : ✳✳✳ Do you want to format?".
   - If you select **Yes**, you will be prompted with the confirmation message "All data will be deleted. Do you want to continue?".

   DVD-RW
   - You will be prompted with the confirmation message "Choose the recording format for DVD-RW."
   - If you select the desired format type, you will be prompted with the confirmation message "All data will be deleted. Do you want to continue?".
4. Press the ◄► buttons to select **Yes**, then press the **OK** button. The disc is formatted.

DVD-VR and DVD-V are defined according to their recording format.

	DVD-VR	DVD-V
DISC	DVD-RAM/-RW	DVD-RW/DVD-R

Downloaded From Disc-Player.com Samsung Manuals







Finalising a Disc

DVD-RW DVD-R

After you record titles onto a DVD-RW/-R disc with your HDD & DVD Recorder, it needs to be finalised before it can be played back on external devices.

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Disc Manager**, then press the **OK** or ► button.
3. Press the ▲▼◄► buttons to select **Finalise**, then press the **OK** button.You will be prompted with the message "Do you want to finalise disc?".
4. Press the ◄► buttons to select **Yes**, then press the **OK** button.
   You will be prompted again with the message "Disc will be finalised. Do you want to continue?".
5. Press the ◄► buttons to select **Yes**, then press the **OK** button.
   The disc is finalised.

- Once a disc is finalised, you cannot delete entries from the record list.
- After being finalised, the DVD-R/-RW(video mode) operates in the same manner as a DVD-Video.
- Depending on the disc type, the displayed screen may be different.
- Finalising time may be different depending on the amount of data recorded on the disc.
- Data on the disc will be damaged if the recorder is powered off during finalisation process.
- You can finalise the disc automatically using EZ Record.
  (See page 32)

Downloaded From Disc-Player.com Samsung Manuals







Unfinalising a Disc (V/VR mode)

DVD-RW

1. With the unit in Stop mode, press the **MENU** button.
2. Press the ▲▼ buttons to select **Disc Manager**, then press the **OK** or ► button.
3. Press the ◄► buttons to select **Unfinalise**, then press the **OK** button. You will be prompted with the message "Do you want to unfinalise disc?".
4. Press the ◄► buttons to select **Yes**, then press the **OK** button. You will be prompted again with the message "Disc will be unfinalised. Do you want to continue?".
5. Press the ◄► buttons to select **Yes**, then press the **OK** button. The disc is unfinalised.

■ A DVD-RW can be finalised or unfinalised in Video mode.

	Finalise	Unfinalise
Mark	DVD-Video(RW)	DVD-RW(V)
Operation	Same as DVD-Video	Additional recording, protection and deletion are possible.

■ A DVD-RW can be finalised or unfinalised in VR mode.

	Finalise	Unfinalise
Mark	DVD-RW(VR:F)	DVD-RW(VR)
Operation	Additional recording, deletion, editing, and protection are impossible.	Additional recording, deletion, editing, and protection are possible.

Downloaded From Disc-Player.com Samsung Manuals

Troubleshooting

If your product malfunctions, go through the checkpoints below before contacting a Samsung authorised service centre.

Power

The input is displayed for a while when the power is turned on.

Checkpoint 1 The HDD & DVD Recorder requires some time to initialise and the input will be displayed for approx. 10 seconds after it is turned on.

Recording

Cannot record TV programmes.

Checkpoint 1 Check whether the power cord is securely plugged into the power outlet.

Checkpoint 2 Did you set the HDD & DVD Recorder channel settings correctly?

Checkpoint 3 Check the free space on your HDD/DVD-RAM/-RW/-R discs.

I pressed the REC button but there is no response.

Checkpoint 1 Check available disc type. (See page 63)
If a programme is copy protected, it cannot be recorded.

Playback

Cannot play the disc.

Checkpoint 1 Check whether the disc is inserted correctly with the label facing up.

Checkpoint 2 Check the regional code of the DVD disc.

Checkpoint 3 This HDD & DVD Recorder cannot play some types of discs.
(See pages 7, 44)

⊘ icon appears on the screen.

Checkpoint 1 You cannot use this operation or function due to one of the following reasons:

(1) Your DVD disc restricts it.

(2) Your DVD disc does not support this feature (for example: angles)

(3) The feature is not available at the moment.

(4) You've requested a title, chapter, or scan time that is out of range.

Play mode settings are different from the settings configured in the Settings menu.

Checkpoint 1 The disc does not support all selected functions. In this case, some settings configured in the settings menu may not work properly.

Cannot change the aspect ratio.

Checkpoint 1 The aspect ratio is fixed for DVD discs.
(See page 35)

The angle operation does not work while playing a DVD disc.

Checkpoint 1 The angle operation is available only when the disc contains images captured from different angles.

The selected audio and/or subtitle language is not played.

Checkpoint 1 Audio and subtitle languages are disc-specific. Only the sound and subtitle languages contained on the DVD disc are available and displayed in the disc menu.

Cannot copy title or file to the other mode.

Checkpoint 1 DVD discs encoded with copy protection can not be copied to HDD.

Checkpoint 2 Refer to "Contents Copy Specifications" on page 6 to check if copying is supported.

Refer to "V-Mode Compatibility" on page 36 to check if copying is support.

Downloaded From Disc-Player.com Samsung Manuals

Video

The disc revolves, but no image or bad quality images is displayed.

Checkpoint 1 Be sure that the Video Setting is properly set. (See pages 35~38)

Checkpoint 2 Check whether there is damage to or any foreign material on your disc.

Checkpoint 3 Some low quality discs may not play properly.

Checkpoint 4 If scenes change from dark to bright suddenly, the screen may shake vertically temporarily, but this is not a fault.

Sound

No sound.

Checkpoint 1 Are you watching a programme in slow or skip mode?

If you are playing a programme at a speed other than normal speed, sound will not be heard. (Except for forward search (X 2) in disc.)

Checkpoint 2 Check the connections and settings. (See pages 21~22, 33~35)

Checkpoint 3 Check whether the disc is damaged. Clean the disc, if necessary.

Checkpoint 4 Check whether the disc is inserted correctly with the label facing up.

No audio output.

Checkpoint 1 Check whether you have selected the correct digital output options in the Audio Output Options menu. (See pages 33~35)

Timer Recording

Timer lamp flickers.

Checkpoint 1 Check there is enough space in the disc or HDD for recording.

Checkpoint 2 Check whether the current disc is recordable or not.

Make sure to check before the start time of recording.

Timer recording does not work properly.

Checkpoint 1 Re-check the recording time and the end time settings again.

Checkpoint 2 Recording will be cancelled if the power is interrupted due to a power failure or another similar reason while recording.

HDMI

No HDMI output.

Checkpoint 1 Check whether the mode is stop mode or not. You can switch HDMI mode in stop mode.

Checkpoint 2 Check the Video output is HDMI enabled.

Checkpoint 3 Check the connection between the TV and the HDMI jack of the HDD & DVD Recorder.

Checkpoint 4 See if your TV supports HDMI.

Abnormal HDMI output screen.

Checkpoint 1 If snow noise appears on the screen, it means that TV does not support HDCP (High-bandwidth Digital Content Protection).

HDMI output Jitter.

Checkpoint 1 Check your TV system setup correctly.

Checkpoint 2 Please refer to the instruction manual of your TV.

Downloaded From Disc-Player.com Samsung Manuals

Remote Control Unit

The remote control doesn't work.

Checkpoint 1 Point the remote control at the remote control sensor on your HDD & DVD Recorder. Allow for proper distance. Remove obstacles between your HDD & DVD Recorder and the remote control.

Checkpoint 2 Check whether the batteries are drained.

Checkpoint 3 Check whether TV, DVD or HDD control button is selected or not.

Other

I forgot my password for parental supervision.

Checkpoint 1 Press and hold the **PROG** (◯ ◯) buttons on the front panel of the Recorder for more than 5 seconds with no disc in the unit. All settings including the password will revert to the factory settings. Do not use this unless absolutely necessary.
(Note that this function is possible only when no disc is inserted.)

Is it possible to change a subtitle and an audio signal on a recorded disc?

Checkpoint 1 A recorded disc is played with only the subtitle and the audio signal which were selected during recording.

Other problems.

Checkpoint 1 Read the table of contents and then find and read the section describing your problem, follow the instructions given.

Checkpoint 2 Plug your HDD & DVD Recorder off and on.

Checkpoint 3 If the problem still persists, contact a nearby Samsung service centre.

Downloaded From Disc-Player.com Samsung Manuals

Specifications

General	Power requirements	220-240 V AC, 50 Hz
	Power consumption	31 Watts / 5 Watts (Power off)
	Weight	4,5 Kg
	Dimensions	430 mm(W) x 336 mm(D) x 59 mm(H)
	Operating temp.	+5 °C to +35 °C
	Other conditions	Keep level when operating. Less than 75% operating humidity
Input	Video	Composite Video : 1.0 V p-p at 75Ω load, sync negative
	Audio	Max.Audio Input Level : 2 Vrms
	DV Input	IEEE 1394(4p) compatible jack
	Receivable Channels	PAL-B/G, B/B, DVB-T
Output	Audio	Analogue output jacks x 2
		Optical/Coaxial digital audio output
	Video	Composite Video : Video output jack x 1
		S-Video output x 1 (Y :1,0Vp-p, C : 0,286Vp-p at 75Ω load)
		Component output x 1 (Y : 1,0Vp-p, Pb : 0,70Vp-p, Pr : 0,70Vp-p at 75Ω load)
		HDMI/DVI (576P, 720P,1080i)
Recording	Picture Compression format	MPEG-II
	Audio Compression format	Dolby Digital 2ch/256Kbps, MPEG-II
	Recording Quality	XP (about 8,5 Mbps), SP (about 4,5 Mbps), LP (about 2,5 Mbps), EP (about 1,6 Mbps or about 1,2 Mbps)
	Audio Frequency Response	20 Hz~20 kHz
HDD Capacity	DVD-SH853	160 GB
	DVD-SH855	250 GB

Audio Output For DVD discs, audio signals recorded at 96 kHz sampling frequency are converted into and output at 48 kHz.

Disc Type	DVD	AUDIO CD(CD-DA)
Analogue Audio Output	48 / 96 kHz	44,1 kHz
Digital Audio Output	48 kHz	44,1 kHz

Downloaded From Disc-Player.com Samsung Manuals

Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

Region	Country	Customer Care Center	Web Site
North America	CANADA	1-800-SAMSUNG (7267864)	www.samsung.com/ca
	MEXICO	01-800-SAMSUNG (7267864)	www.samsung.com/mx
	U.S.A	1-800-SAMSUNG (7267864)	www.samsung.com
Latin America	ARGENTINE	0800-333-3733	www.samsung.com/ar
	BRAZIL	0800-124-421 4004-0000	www.samsung.com/br
	CHILE	800-726-7864 (SAMSUNG)	www.samsung.com/cl
	COSTA RICA	0-800-507-7267	www.samsung.com/latin
	ECUADOR	1-800-10-7267	www.samsung.com/latin
	EL SALVADOR	800-6225	www.samsung.com/latin
	GUATEMALA	1-800-299-0013	www.samsung.com/latin
	JAMAICA	1-800-234-7267	www.samsung.com/latin
	PANAMA	800-7267	www.samsung.com/latin
	PUERTO RICO	1-800-682-3180	www.samsung.com/latin
	REP. DOMINICA	1-800-751-2676	www.samsung.com/latin
	TRINIDAD & TOBAGO	1-800-7267-864	www.samsung.com/latin
	VENEZUELA	0-800-100-5303	www.samsung.com/latin
	COLOMBIA	01-8000112112	www.samsung.com.co
Europe	BELGIUM	02 201 2418	www.samsung.com/be
	CZECH REPUBLIC	844 000 844 Distributor pro Českou republiku : Samsung Zrt., česka organizační složka Vyskočilova 4, 14000 Praha 4	www.samsung.com/cz
	DENMARK	70 70 19 70	www.samsung.com/dk
	FINLAND	030-6227 515	www.samsung.com/fi
	FRANCE	3260 SAMSUNG or 08 25 08 65 65 (€ 0,15/Min)	www.samsung.com/fr
	GERMANY	01805 - 121213 (€ 0,14/Min)	www.samsung.de
	HUNGARY	06-80-SAMSUNG (7267864)	www.samsung.com/hu
	ITALIA	800-SAMSUNG (7267864)	www.samsung.com/it
	LUXEMBURG	0032 (0)2 201 24 18	www.samsung.lu
	NETHERLANDS	0900 20 200 88 (€ 0,10/Min)	www.samsung.com/nl
	NORWAY	815-56 480	www.samsung.com/no
	POLAND	0 801 801 881	www.samsung.com/pl
	PORTUGAL	80 8 200 128	www.samsung.com/pt
	SLOVAKIA	0800-SAMSUNG (726786)	www.samsung.com/sk
	SPAIN	902 10 11 30	www.samsung.com/es
	SWEDEN	0771-400 200	www.samsung.com/se
	U.K	0870 SAMSUNG (7267864)	www.samsung.com/uk
	Republic of Ireland	0818 717 100	www.samsung.com/uk
	Switzerland	0800-7267864	www.samsung.com/ch
CIS	RUSSIA	8-800-200-0400	www.samsung.ru
	KAZAHSTAN	8-800-080-1188	www.samsung.kz
	UZBEKISTAN	8-800-120-0400	www.samsung.uz
	UKRAINE	8-800-502-0000	www.samsung.com/ur
	LITHUANIA	8-800-77777	www.samsung.lt
	LATVIA	800-7267	www.samsung.com/lv/index.htm
	ESTONIA	800-7267	www.samsung.ee
Asia Pacific	AUSTRALIA	1300 362 603	www.samsung.com/au
	CHINA	800-810-5858, 010-6475 1880	www.samsung.com.cn
	HONG KONG	3698 - 4698	www.samsung.com/hk
	INDIA	3030 8282 1800 110011	www.samsung.com/in
	INDONESIA	0800-112-8888	www.samsung.com/id
	JAPAN	0120-327-527	www.samsung.com/jp
	MALAYSIA	1800-88-9999	www.samsung.com/my
	PHILIPPINES	1800-10-SAMSUNG (7267864)	www.samsung.com/ph
	SINGAPORE	1800-SAMSUNG (7267864)	www.samsung.com/sg
	THAILAND	1800-29-3232 02-689-3232	www.samsung.com/th
	TAIWAN	0800-329-999	www.samsung.com/tw
	VIETNAM	1 800 588 889	www.samsung.com/vn
Middle East & Africa	SOUTH AFRICA	0860 7267864 (SAMSUNG)	www.samsung.com/za
	U.A.E	800SAMSUNG (7267864) 8000-4726	www.samsung.com/mea

Downloaded From Disc-Player.com Samsung Manuals

Correct Disposal of This Product
(Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)
This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

AK68-01462A-01

Downloaded From Disc-Player.com Samsung Manuals